
GROUP 54**CHASSIS
ELECTRICAL****CONTENTS**

CHASSIS ELECTRICAL	54A
SIMPLIFIED WIRING SYSTEM (SWS)	54B

GROUP 54A

CHASSIS ELECTRICAL

CONTENTS

BATTERY	54A-5	IGNITION SWITCH	54A-27
ON-VEHICLE SERVICE	54A-5	REMOVAL AND INSTALLATION.....	54A-27
BATTERY CHECK.....	54A-5	INSPECTION.....	54A-28
BATTERY CHARGING.....	54A-6	COMBINATION METERS	
BATTERY TEST.....	54A-6	ASSEMBLY AND VEHICLE	
REMOVAL AND INSTALLATION .	54A-8	SPEED SENSOR	54A-29
IGNITION SWITCH	54A-8	INTRODUCTION	54A-29
GENERAL DESCRIPTION	54A-8	INTRODUCTION TO COMBINATION METERS	
IGNITION SWITCH DIAGNOSIS ..	54A-9	ASSEMBLY AND DIAGNOSIS.....	54A-29
IGNITION SYSTEM DIAGNOSIS.....	54A-9	TROUBLESHOOTING STRATEGY....	54A-29
INTRODUCTION TO IGNITION SWITCH		TROUBLE SYMPTOM CHART.....	54A-29
DIAGNOSIS.....	54A-9	SYMPTOM PROCEDURES.....	54A-30
TROUBLESHOOTING STRATEGY...	54A-9	SPECIAL TOOLS	54A-63
TROUBLE CODE DIAGNOSIS.....	54A-10	ON-VEHICLE SERVICE	54A-63
DIAGNOSTIC TROUBLE CODE CHART	54A-10	SPEEDOMETER CHECK.....	54A-63
DIAGNOSTIC TROUBLE CODE		TACHOMETER CHECK.....	54A-64
PROCEDURES.....	54A-11	FUEL GAUGE UNIT CHECK.....	54A-65
TROUBLE SYMPTOM CHART.....	54A-14	ENGINE COOLANT TEMPERATURE	
SYMPTOM PROCEDURES.....	54A-15	GAUGE UNIT CHECK.....	54A-66
DATA LIST REFERENCE TABLE.....	54A-22	COMBINATION METERS ASSEMBLY	
CHECK AT ECU TERMINAL.....	54A-22	AND VEHICLE SPEED SENSOR ..	54A-66
ON-VEHICLE SERVICE	54A-22	REMOVAL AND INSTALLATION.....	54A-66
IMMOBILIZER ID CODE REGISTRATION	54A-22	VEHICLES SPEED SENSOR CHECK..	54A-67
SPECIAL TOOLS	54A-26	FUEL GAUGE RESISTANCE CHECK..	54A-67
		ENGINE COOLANT TEMPERATURE	
		GAUGE RESISTANCE CHECK.....	54A-68
		DISASSEMBLY AND REASSEMBLY ..	54A-68

HEADLIGHT, FRONT SIDE MARKER LIGHT AND POSITION LIGHT ASSEMBLY	54A-69	BACK-UP LIGHT	54A-81
LIGHTING SYSTEM DIAGNOSIS	54A-69	BACK-UP LIGHT DIAGNOSIS	54A-81
INTRODUCTION TO LIGHTING DIAGNOSIS	54A-69	REMOVAL AND INSTALLATION	54A-81
ON-VEHICLE SERVICE	54A-69	DOME LIGHT	54A-82
HEADLIGHT AIMING	54A-69	DOME LIGHT DIAGNOSIS	54A-85
LUMINOUS INTENSITY MEASUREMENT	54A-71	HIGH-MOUNTED STOPLIGHT	54A-83
REPLACEMENT OF REPLACEABLE BULB	54A-72	REMOVAL AND INSTALLATION	54A-83
HEADLIGHT	54A-73	RHEOSTAT	54A-84
REMOVAL AND INSTALLATION	54A-73	REMOVAL AND INSTALLATION	54A-84
HEADLIGHT RELAY CHECK	54A-74	INSPECTION	54A-84
FOG LIGHT	54A-74	HAZARD WARNING LIGHT SWITCH	54A-85
LIGHTING SYSTEM DIAGNOSIS	54A-76	HAZARD WARNING LIGHT SWITCH DIAGNOSIS	54A-85
INTRODUCTION	54A-74	HAZARD WARNING LIGHT SWITCH	54A-85
ON-VEHICLE SERVICE	54A-74	REMOVAL AND INSTALLATION	54A-85
FOG LIGHT AIMING	54A-74	INSPECTION	54A-85
FOG LIGHT	54A-76	COLUMN SWITCH	54A-86
REMOVAL AND INSTALLATION	54A-76	REMOVAL AND INSTALLATION	54A-86
FRONT FOG LIGHT SWITCH CHECK	54A-77	COLUMN SWITCH CHECK	54A-87
FRONT FOG LIGHT RELAY CHECK	54A-77	HORN	54A-89
FRONT COMBINATION LIGHT	54A-78	HORN DIAGNOSIS	54A-89
FRONT COMBINATION LIGHT DIAGNOSIS	54A-78	HORN	54A-89
REMOVAL AND INSTALLATION	54A-78	REMOVAL AND INSTALLATION	54A-89
TAILLIGHT SWITCH CHECK	54A-79	HORN CHECK	54A-90
REAR COMBINATION LIGHT	54A-80		
LIGHTING SYSTEM DIAGNOSIS	54A-80		
REAR COMBINATION LIGHT	54A-80		
REMOVAL AND INSTALLATION	54A-80		

CIGARETTE LIGHTER, ACCESSORY SOCKET	54A-90	ANTENNA POLE REPLACEMENT	54A-188
REMOVAL AND INSTALLATION .	54A-90	REAR WINDOW DEFOGGER .	54A-189
CIGARETTE LIGHTER INSPECTION	54A-91	ON-VEHICLE SERVICE	54A-189
RADIO AND TAPE PLAYER	54A-91	PRINTED-HEATER LINES CHECK	54A-189
RADIO WITH TAPE PLAYER AND CD PLAYER, SPEAKER AND ANTENNA DIAGNOSIS	54A-91	REAR WINDOW DEFOGGER SWITCH	54A-189
INTRODUCTION TO AUDIO SYSTEM DIAGNOSIS	54A-91	REMOVAL AND INSTALLATION	54A-189
TROUBLESHOOTING STRATEGY	54A-91	INSPECTION	54A-189
TROUBLE SYMPTOM CHART	54A-92	DEFOGGER RELAY CHECK	54A-190
SYMPTOM PROCEDURES	54A-94	MULTI-CENTER DISPLAY	54A-190
SPECIAL TOOLS	54A-176	MULTI-CENTER DISPLAY DIAGNOSIS	54A-190
ON-VEHICLE SERVICE	54A-176	TROUBLE SYMPTOM CHART	54A-190
PROCEDURE FOR INPUT OF ANTI-THEFT CODE FOR ANTI-THEFT SYSTEM	54A-176	SYMPTOM PROCEDURES	54A-191
SPEAKER TEST	54A-178	ON-VEHICLE SERVICE	54A-210
RADIO WITH TAPE PLAYER AND CD PLAYER	54A-180	CAMPASS CALIBRATION	54A-210
REMOVAL AND INSTALLATION	54A-180	VEHICLE MAGNETIC COMPENSATION	54A-212
SPEAKER	54A-181	REMOVAL AND INSTALLATION .	54A-213
REMOVAL AND INSTALLATION .	54A-181	SPECIAL TOOLS	54A-214
AMPLIFIER	54A-183	THEFT ALARM	54A-214
REMOVAL AND INSTALLATION .	54A-183	THEFT-ALARM SYSTEM DIAGNOSIS	54A-214
ANTENNA	54A-184	REMOVAL AND INSTALLATION .	54A-214
REMOVAL AND INSTALLATION .	54A-186	SPECIFICATIONS	54A-215
GLASS ANTENNA CHECK	54A-187	FASTENER TIGHTENING SPECIFICATIONS	54A-215
ANTENNA INSPECTION	54A-187	SERVICE SPECIFICATIONS	54A-215
		SEALANT	54A-216

BATTERY

ON-VEHICLE SERVICE

BATTERY CHECK


M1541001000074

⚠ WARNING

Battery posts, terminals and related accessories contain lead and lead compounds. WASH HANDS AFTER HANDLING.

BATTERY VISUAL INSPECTION (1)

The battery contains a visual test indicator which gives a blue signal when an adequate charge level exists, and a white signal when charging is required.



BATTERY VISUAL INSPECTION (2)

Make sure ignition switch is in "LOCK"(OFF) position and all battery fed accessories are OFF.

1. Disconnect the negative cable from battery before disconnecting the positive cable.

⚠ WARNING

Care should be taken in the event battery case is cracked or leaking to protect hands from the electrolyte. A suitable pair of rubber gloves (not the household type) should be worn when removing battery by hand.

2. Remove the battery from the vehicle.

3. Inspect the battery carrier for damage caused by loss of acid from battery. If acid damage is present, it is necessary to clean area with a solution of clean warm water and baking soda. Scrub area with a stiff bristle brush. Wipe clean with a cloth moistened with ammonia or baking soda in water.
4. Clean the battery, especially the top with same solutions as described in step 3.
5. Inspect the battery case and cover for cracks. If cracks are present, battery must be replaced.
6. Clean the battery post with a suitable battery post cleaning tool.
7. Clean the inside surfaces of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
8. Install the battery in the vehicle.
9. Connect the positive and negative cables to the battery in the order of mention.
10. Tighten the clamp nut securely.

BATTERY CHARGING

M1541001100071



WARNING

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries on charge or which have recently been charged. Do not break live circuits at the terminals of the batteries on charge. A spark will occur where the live circuit is broken. Keep all open flames away from the battery.

Battery electrolyte temperature may temporarily be allowed to rise to 55°C (131°F). Increase of electrolyte temperature above 55°C (131°F) is harmful to the battery, causing deformation of battery cell, decrease in life of battery, etc.

CHARGE RATE

If the test indicator is white, the battery should be charged as outlined below. When the dot appears or when maximum charge shown below is reached, charging should be stopped.

Charge Rate Chart

BATTERY	BCI Group size 86
Slow charging	5 amps 15 hours
	10 amps 7.5 hours
Fast charging	20 amps 3.75 hours
	30 amps 2.5 hours

BATTERY TEST

M1541001200078

BATTERY TESTING PROCEDURE

connections?

YES : Clean the battery cables. Then go to Step 2.
NO : Go to Step 2.

STEP 1. Check the battery cables.

Remove the negative cable, then the positive cable. Check for dirty or corroded connections.

Q: Are the battery cables dirty or have corroded

TSB Revision

STEP 2. Check the battery post.

Check for loose battery post.

Q: Are the battery post faulty?

- Yes** : Replace the battery. Then go to Step 4.
- NO** : Go to Step 3.

STEP 3. Check the battery case and cover.

- (1))Remove the hold-downs and shields.
- (2) Check for broken/cracked case or cover.

Q: Is the battery case or cover faulty?

- YES** : Replace the battery. Then go to Step 4.
- NO** : Go to Step 4.

STEP 4. Check the open circuit voltage.

- (1) Turn headlights on for 15 seconds.
- (2) Turn headlights off for two minutes to allow battery positive voltage to stabilize.
- (3) Disconnect the battery cables.
- (4) Read open circuit voltage.

Q: Is open circuit voltage 12.4 volts or more?

- NO** : Go to Step 5.
- YES** : Go to Step 6.

STEP 5. Charge battery.

Q: Charging the battery?

- YES** : Charge the battery at 5 amps for 15 hours. Then re-test, go to Step 4.
- NO** : Go to Step6.

STEP 6. Check the load test.

- (1) Connect a load tester to the battery.
- (2) Load the battery at the recommended discharge rate (See LOAD TEST RATE CHART) for 15 seconds.
- (3) Read voltage after 15 seconds, then remove load.
- (4) Compare the measured value with the minimum voltage. (See LOAD TEST CHART.)

Q: Is the voltage higher than minimum voltage?

- NO** : Replace the battery. Then go to Step 4.
- YES** : The battery is normal.

LOAD TEST CHART


TEMPERATURE °C (°F)	21 (70) AND ABOVE	16 (60)	10 (50)	4 (40)	-1 (30)	-7 (20)	-12 (10)	-18 (0)
Minimum voltage	9.6	9.5	9.4	9.3	9.1	8.9	8.7	8.5

LOAD TEST RATE CHART

Load test	252 amps
Cranking ratio (0°F)	525 amps
Reserve capacity	90 minutes
Application	BCI Group size 86

REMOVAL AND INSTALLATION

M1541001300053



AC001251AB

REMOVAL STEPS

1. ACCELERATOR CABLE CLAMP
2. BATTERY HOLDER

REMOVAL STEPS (Continued)

3. BATTERY COVER
4. BATTERY

IGNITION SWITCH

GENERAL DESCRIPTION

Ignition key reminder tone alarm

The ignition key reminder tone alarm will sound under the following condition, and warn the driver to remove the ignition key.

M1543009900248

- The driver's door is opened when the ignition switch is at "LOCK" (OFF) or "ACC" position without removing the ignition key. However, the light reminder tone alarm will take precedence over this function.

TSB Revision

IMMOBILIZER SYSTEM

The immobilizer system consists of the ignition key, the key ring antenna, the immobilizer-ECU, and the ECM <M/T> or PCM <A/T>. The ignition key has a built-in transponder. The key ring antenna is installed on the steering lock key cylinder. Only the registered ignition key permits the engine to start, therefore, the engine can never be started by means of a forged key or by connecting the ignition wiring directly. The

system is significantly safe and reliable against theft. In addition, the driver has only to turn the ignition switch to the "ON" position to activate the immobilizer system. If the requirements for starting the engine are not satisfied, the engine will be immobilized. If the ignition key is lost or another ignition key is added, the encrypted code can be registered or erased by using scan tool MB991502.

IGNITION SWITCH DIAGNOSIS

IGNITION SWITCH DIAGNOSIS

The Ignition key reminder horn alarms are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-9](#).

M1543000700269

INTRODUCTION TO IMMOBILIZER SYSTEM DIAGNOSIS

M1543009900259

CAUTION

- The encrypted code should always be re-registered when replacing the immobilizer-ECU.
- If the immobilizer-ECU has been replaced with a new part, the password (vehicle secret code) which has been stored in the immobilizer-ECU for each vehicle will be replaced by a new password (secret code) specified by the customer.

The immobilizer system consists of the immobilizer-ECU, ECM <M/T> or PCM <A/T>, ignition key and ignition key ring antenna. If the engine cannot be started by using a registered ignition key, one of these components may be defective. In addition, if

the immobilizer system has immobilized the engine, MFI system DTC P1610 will be output. In this case, observe the immobilizer system troubleshooting. Then, if a malfunction is resolved, the MFI system DTC P1610 should not reset.

IMMOBILIZER SYSTEM DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1543006900153

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find an immobilizer system fault.

1. Gather information about the problem from the customer.
2. Verify that the condition described by the customer exists.
3. Check the vehicle for any immobilizer system DTC.
4. If you cannot verify the condition and there are no immobilizer system DTCs, the malfunction is intermittent. Refer to GROUP 00, How to Use Troubleshooting/inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-6](#).
5. If you can verify the condition but there are no immobilizer system DTCs, or the system cannot communicate with scan tool MB991502, refer to Symptom Chart [P.54A-14](#) and find the fault.
6. If there is an immobilizer system DTC, record the number of the DTC, then erase the DTC from the memory using scan tool MB991502.
7. Recreate the immobilizer system DTC set conditions to see if the same immobilizer system DTC will set again.
 - If the same immobilize system DTC sets again, perform the diagnostic procedures for the DTC. Refer to Diagnostic Trouble Code Chart.
 - If you cannot get the same immobilizer system DTC to set again, the malfunction is intermittent. Refer to GROUP 00, How to Use Troubleshooting/inspection Service Points – How to Cope with Intermittent Malfunctions [P.00-6](#).

**IMMOBILIZER SYSTEM TROUBLE CODE
DIAGNOSIS**

M1543007000089


**Retrieving and Erasing Immobilizer System
Diagnostic Trouble Codes****Required Special Tool:**

MB991502: Scan Tool (MUT-II)

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

1. Connect scan tool MB991502 to data link connector (16 pin).
2. Turn the ignition switch to "ON" position.
3. Use scan tool MB991502 to check or erase immobilizer system diagnostic trouble codes.
4. Turn the ignition switch to "LOCK" (OFF) position.
5. Disconnect scan tool MB991502.

**DIAGNOSTIC TROUBLE CODE CHART**

M1543007100105

Follow the inspection chart that is appropriate for the diagnostic trouble code.


DIAGNOSTIC TROUBLE CODE NO.	DESCRIPTION	REFERENCE PAGE
11	Transponder communication system or radio interference of encrypted code	P.54A-11
12	Encrypted codes are not the same or are not registered	P.54A-14

NOTE: Diagnostic trouble code is not recorded.



DIAGNOSTIC TROUBLE CODE PROCEDURES

DTC: 11 Transponder Communication System or Radio Interference of Encrypted Code

Ignition Key Ring Antenna Circuit



W0815M00A
AC004736AB



CIRCUIT OPERATION

The ignition key is powered by the ignition key ring antenna, and sends an encrypted code. The ignition key ring antenna receives the encrypted code, and determines whether the ignition key is a registered key or not.

DTC SET CONDITION

- If the engine is started while several ignition keys are in the vicinity, interference between the different keys may occur, which will cause this code to be generated.
- The encrypted code of the transponder is not sent to the immobilizer-ECU immediately after the ignition switch is turned to "ON" position.

NOTE: DTC 11 is always output together with MFI system DTC P1610.

TROUBLESHOOTING HINTS

- Radio interference of encrypted code
- Malfunction of transponder
- Malfunction of ignition key ring antenna
- Malfunction of immobilizer-ECU
- Damaged wiring harness of connectors

TSB Revision

DIAGNOSIS**Required Special Tools:**

- MB991223: Harness Set
- MB991502: Scan Tool

STEP 1. Check there is another key near the ignition key.**Q: Is there any other key near the ignition key?**

- YES :** Move the other key well away from key being used.
Confirm that diagnostic trouble code 11 is not output.
- NO :** Go to Step 2.

STEP 2. Check that the engine starts using the spare ignition key which encrypted code has been registered.**Q: Does the engine start using the spare ignition key which encrypted code has been registered?**

- YES :** Replace the ignition key that does not work. Then register the password (secret code) and encrypted code [P.54A-22](#). Confirm that diagnostic trouble code 11 is not output.
- NO :** Go to Step 3.

STEP 3. Check which DTC is output, DTC1 or DTC12.**Q: Which DTC is output, DTC 11 or 12?**


- DTC12 is output :** Refer to DTC 12 [P.54A-14](#).
- DTC11 is output :** Go to Step 4.



STEP 4. Check the ignition key ring antenna by backprobing.

Do not disconnect the ignition key ring antenna connector C-88 and check the resistance on the harness side connector between terminal number 3 and terminal number 7 by backprobing.

Q: Is the resistance less than two ohm?

- YES :** Go to Step 5.
- NO :** Replace the ignition key ring antenna. Confirm that diagnostic trouble code 11 is not output.







STEP 5. Check immobilizer-ECU connector C-79 and ignition key ring antenna connector C-88 for damage.
Q: Are immobilizer-ECU connector C-79 and ignition key ring antenna connector C-88 in good condition?

YES : Go to Step 6 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Confirm that diagnostic trouble code 11 is not output.



STEP 6. Check the harness wires between immobilizer-ECU connector C-79 and ignition key ring antenna connector C-88.

Q: Are the harness wires between immobilizer-ECU connector C-79 and ignition key ring antenna connector C-88 in good condition?

YES : Replace the immobilizer-ECU. Then register the password (secret code) and encrypted code (Refer to [P.54A-22](#).) Confirm that diagnostic trouble code 11 is not output.

NO : Repair them. Confirm that diagnostic trouble code 11 is not output.

DTC12: Encrypted codes are not the same or not registered**DTC SET CONDITION**

The encrypted code which is sent from the transponder is not the same as the encrypted code which is registered in the immobilizer-ECU.

NOTE: DTC 12 is always output together with MFI system DTC P1610.

TROUBLESHOOTING HINTS

- The encrypted code in the ignition key being used has not been properly registered
- Malfunction of immobilizer-ECU

DIAGNOSIS**STEP 1. Check that the encrypted code was registered.****Q: Was the encrypted code registered?**

YES : Replace the immobilizer and then re-register the encrypted code (Refer to [P.54A-22.](#))

NO : Register the encrypted code (Refer to [P.54A-22.](#))

TROUBLE SYMPTOM CHART




M1543007200209



SYMPTOMS	INSPECTION PROCEDURE NO.	REFERENCE PAGE
Communication with scan tool is impossible	1	P.54A-15
Registering the ignition key is impossible	2	P.54A-20
Engine does not start (Cranking but no initial combustion)	3	P.54A-21

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Communication with scan tool MB991502 is impossible.

Immobilizer-ECU Power Supply, Ground and ECM <M/T> or PCM <A/T>
Communication Line Circuit





Communication with scan tool MB991502 is impossible

Immobilizer-ECU is energized when the ignition switch is turned "ON," and the MFI relay is turned on. The ECM <M/T> or PCM <A/T> transmits a signal from scan tool MB991502 to the immobilizer-ECU as it is. In the same way, a signal from the immobilizer-ECU is also transmitted to scan tool MB991502 as it is.

TECHNICAL DESCRIPTION (COMMENT)

- This malfunction may be caused by a defective immobilizer-ECU, ECM <M/T> or PCM <A/T>, or a defect in the communication line between the immobilizer-ECU and ECM <M/T> or PCM <A/T>. If this malfunction appears when the MFI system and scan tool MB991502 can communicate each other, MFI system DTC P1610 will reset.

- If the MFI system is normal, the MFI relay can be determined as normal. In addition, if the MFI system and scan tool MB991502 can communicate each other, the circuits between the data link connector and the ECM <M/T> or PCM <A/T> can be determined as normal.

NOTE: If this malfunction appears, MFI system DTC P1610 will be output.

TROUBLESHOOTING HINTS

- Malfunction of immobilizer-ECU
- Malfunction of ECM <M/T> or PCM <A/T>
- Damaged harness wires or connectors

DIAGNOSIS

Required Special Tools:

- MB991223: Harness Set
- MB991502: Scan Tool (MUT-II)


STEP 1. Check scan tool MB991502 communicates with the MFI system and MFI system DTC output other than P1610.

Q: Can scan tool MB991502 communicate with the MFI system? Does MFI system DTC other than P1610 reset?

YES : Go to Step 2.

NO : Refer to GROUP 13A, Diagnosis [P.13A-20](#) or GROUP 13B, Diagnosis [P.13A-20](#).

CONNECTOR: C-79
(HARNES SIDE)



ACX01728AF

STEP 2. Check the immobilizer-ECU power supply circuit by backprobing.


- (1) Do not disconnect immobilizer-ECU connector C-79.
- (2) Turn the ignition switch to the "ON" position.
- (3) Measure the voltage between terminal 7 and ground by backprobing.

Q: Is the voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 5.

NO : Go to Step 3.

CONNECTOR: A-21X



AC001655AB


STEP 3. Check immobilizer-ECU connector C-79 and MFI relay connector A-21X for damage.

Q: Are immobilizer-ECU connector C-79 and MFI relay connector A-21X damaged?




YES : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Confirm that scan tool MB991502 communicates normally.

NO : Go to Step 4.

CONNECTOR: C-79



AC001652AC




STEP 4. Check the harness wires between immobilizer-ECU connector C-79 and MFI relay connector A-21X.

NOTE: After checking intermediate connector C-28, check the wires. If intermediate connector C-28 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between immobilizer-ECU connector C-79 and MFI relay connector A-21X damaged?

YES : Replace them. Confirm that scan tool MB991502 communicates normally.

NO : There is no action to be taken.




STEP 5. Check the immobilizer-ECU ground circuit by backprobing.

- (1) Do not disconnect immobilizer-ECU connector C-79.
- (2) Measure the resistance between terminal 3 and ground by backprobing.

Q: Is the resistance less than two ohm?

YES : Go to Step 7.

NO : Go to Step 8.




STEP 6. Check immobilizer-ECU connector C-79 for damage.

Q: Is immobilizer-ECU connector C-79 in good condition?

YES : Go to Step 7 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Confirm that scan tool MB991502 communicates normally.




STEP 7. Check the harness wire between immobilizer-ECU connector C-79 and ground.

Q: Is the harness wire between immobilizer-ECU connector C-79 and ground damaged?

YES : Repair it. Confirm that scan tool MB991502 communicates normally.

NO : There is no action to be taken.




STEP 8. Check the harness wires between immobilizer-ECU connector C-79 and ECM connector C-56<2.4L M/T>, C-62<3.0L M/T> or PCM connector C-61<2.4L A/T>, C-63<3.0L A/T>.

Q: Are the harness wires between immobilizer-ECU connector C-79 and ECM connector C-56<2.4L M/T>, C-62<3.0L M/T> or PCM connector C-61<2.4L A/T>, C-63<3.0L A/T> damaged?

YES : Repair them. Confirm that scan tool MB991502 communicates normally.

NO : Go to Step 9.



STEP 9. Replace the immobilizer-ECU or ECM <M/T> or PCM <A/T>.

Replace the immobilizer-ECU or ECM <M/T> or PCM <A/T>.

Q: Did the communication with MUT-II become possible after replacing the immobilizer-ECU or the power train control module?

YES : Register the password (secret code) and encrypted code (Refer to [P.54A-22](#).) Confirm that scan tool MB991502 communicates normally.

NO : Go to Step 10.

STEP 10. Recheck for malfunction**Q: Is a malfunction eliminated?**

YES : This diagnosis is complete. (If no malfunction are not found in all steps, an intermittent malfunction is suspected. Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction [P.00-6](#).)

NO : Replace the immobilizer-ECU or ECM <M/T> or PCM <A/T>.

INSPECTION PROCEDURE 2: Registering the ignition key is impossible.**TECHNICAL DESCRIPTION (COMMENT)**

The transponder built-in ignition key or the immobilizer-ECU is suspected to be defective.

TROUBLESHOOTING HINTS

- Malfunction of ignition key
- Malfunction of immobilizer-ECU

DIAGNOSIS**Required Special Tools:**

- MB991223: Harness Set
- MB991502: Scan Tool

STEP 1. Check the DTC 11.**Q: Does DTC11 reset?**

YES : Refer to [P.54A-11](#).

NO : Replace the ignition key that cannot be registered. Then re-register the encrypted code [P.54A-22](#). Check that the ignition key can be registered. Then Go to Step 2.

STEP 2. Recheck for malfunction**Q: Is a malfunction eliminated?**

YES : This diagnosis is complete. (If no malfunction are not found in all steps, an intermittent malfunction is suspected. Refer to INTRODUCTION, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction [P.00-6](#).)

NO : Replace the immobilizer-ECU.

INSPECTION PROCEDURE 3: Engine does not start (Cranking but no initial combustion).

TECHNICAL DESCRIPTION (COMMENT)

If the fuel injectors are not operating, there might be a problem with the MFI system in addition to a malfunction of the immobilizer system. It is normal for this to occur if an attempt is made to start the engine using a key that has not been properly registered.

TROUBLESHOOTING HINTS

- Malfunction of MFI system
- Malfunction of immobilizer-ECU

DIAGNOSIS

Required Special Tools:

- MB991223: Harness Set
- MB991502: Scan Tool

STEP 1. Check the battery positive voltage.

Measure the battery positive voltage during cranking.

Q: Is the voltage 8 volts or more?

YES : Go to Step.

NO : Check the battery. Refer to [P.54A-5](#). The engine should start.

STEP 2. Check the immobilizer system DTC and MFI system DTC.

Q: Which DTC resets, the immobilizer system DTC or the MFI system DTC?

Immobilizer system DTC : Refer to [P.54A-10](#).

MFI system DTC : Refer to GROUP 13A [P.13A-20](#), Diagnosis or GROUP 13B [P.13B-18](#), Diagnosis .

No DTC : Go to Step 3.

STEP 3. Check the starting system.

Q: Does the engine start?

YES : Go to Step 4.

NO : Refer to GROUP 13A, Diagnosis – Symptom Chart [P.13A-22](#) or GROUP 13B [P.13B-21](#), Diagnosis – Symptom Chart. If a malfunction is not resolved, replace the immobilizer-ECU. Then register the password (secret code) and encrypted code. (Refer to [P.54A-22](#).) The engine should start.

STEP 4. Recheck for malfunction

Q: Is a malfunction eliminated?

YES : This diagnosis is complete.(If no malfunction are not found in all steps, an intermittent malfunction is suspected. Refer to INTRODUCTION, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction [P.00-6](#).)

NO : Replace the immobilizer-ECU.

DATA LIST REFERENCE TABLE


M1543007300109

MUT-II SCAN TOOL DISPLAY	ITEM NO.	INSPECTION ITEM	INSPECTION REQUIREMENT	NORMAL CONDITION
KEY REGISTERED	01	Key has been registered	–	Number of registered ignition keys

CHECK AT IMMOBILIZER-ECU

M1543007600188

TERMINAL VOLTAGE CHECK



ACX01564 AB

TERMINAL NO.	SIGNAL	CHECKING REQUIREMENT	TERMINAL VOLTAGE
3	Immobilizer-ECU ground	Always	0V
5	ECM <M/T> or PCM <A/T>	–	–
7	Immobilizer-ECU power supply	Ignition switch: "LOCK" (OFF)	0V
		Ignition switch: "ON"	Battery positive voltage
10	Ignition key ring antenna	–	–
11	Ignition key ring antenna	–	–

ON-VEHICLE SERVICE

IMMOBILIZER ENCRYPTED CODE
REGISTRATION

M1543008100175

ENCRYPTED CODE REGISTRATION METHOD

Required Special Tool:

MB991502: Scan Tool (MUT-II)

⚠ CAUTION

Because registering the encrypted codes is done after all previously-registered codes have been erased, you should keep all of the ignition keys that have already been registered accessible.

If the ignition key, Immobilizer-ECU, ECM <M/T> or PCM <A/T> is replaced or an ignition key is added, encrypted codes of all the ignition keys must be registered. (A maximum of eight different ignition key can be registered.) Moreover, when the immobilizer-ECU has been replaced, you will need to use scan tool MB991502 to register the immobilizer-ECU and input the vehicle secret code and to register the password (secret code) that the owner specifies into the immobilizer-ECU.

NOTE: ECM <MIT> or PCM <AIT> has an encrypted code for immobilizer-ECU, and the encrypted code is registered in the immobilizer-ECU and ignition key.

TSB Revision

POINTS TO NOTE DURING OPERATION

If none of the functions can be used, check the diagnostic trouble codes, and after carrying out any necessary repairs, repeat the operation.

If an incorrect password is input five times in a row, the immobilizer-ECU judges that an unauthorized operation is being attempted. Start-prevention mode will be set, and engine operation will stop and all special functions will be disabled. If the ignition switch is turned to "ON" position and left in that position for approximately 20 minutes, "Unauthorized operation, start-prevention mode" will be cancelled.

KEY ID REGISTER

⚠ CAUTION


To prevent damage to scan tool MB991502, always turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

NOTE: Using the key ENCRYPTED register function will cause all key ENCRYPTED that have been previously registered in the immobilizer-ECU to be erased. All keys need to be registered. Those which have been registered before should be on hand before using this function.


NOTE: If registering more than one key, do not disconnect scan tool MB991502 halfway through the registration process.


NOTE: After registering key IDs, check that the engine can be started using all of the keys that have been registered. If the engine will not start, refer to Immobilizer System Diagnosis P.54A-14.

1. Connect scan tool MB991502 to data link connector (16 pin).
2. Turn the ignition switch to "ON" position.




3. At "System Select," press "YES."






4. Select "Immobilizer," press "YES."




5. Select "Special Func," press "YES."



6. Select "key ID register," press "YES."


If DTC 11 exists, "Can't execute" will be displayed. Check for DTC 11. (Refer to [P.54A-14.](#))




7. Input the password. Use the "UP" and "DOWN" keys to change the current password digit to a value between 0 and 9. Use the "LEFT" and "RIGHT" keys to move to a different password digit. Press the "YES" key to accept the password.


NOTE: Four separate digits must be input to make up the password.

If an incorrect password is input five times in a row, this screen is displayed and the Immobilizer-ECU switches to unauthorized operation, start-prevention mode.





8. Press the "YES" key to start key ID registration.



9. This will be displayed when the key ID registration is successful. If an error occurs during key ID registration, the message "Can't execute" will be displayed. If the key has already been registered, "Key ID has been registered" will be displayed.



10. The number of keys currently registered will be displayed. To register an additional key, replace the ignition key with the next key to be registered within five seconds and then press the "YES" key. Key ID registration screen will be displayed, then register another key.

NOTE: A maximum of eight different keys can be registered.

If key ID registration is complete, press the "NO" key.

11. This completes the registration operation. Turn the ignition switch "LOCK" (OFF) and leave it off for approximately ten seconds.

12. Check that the engine can be started with each of the ignition keys.



13. Check that the immobilizer system DTC and MFI system DTC did not set.

14. Turn the ignition switch to "LOCK" (OFF) position.

15. Disconnect scan tool MB991502.


SPECIAL TOOLS

M1543000600240

TOOL	TOOL NUMBER AND NAME	SUPERSESSSION	APPLICATION
 <p>B991502</p>	<p>MB991502 Scan tool (MUT-II)</p>	<p>MB991496-OD</p>	<ul style="list-style-type: none"> • Immobilizer system check • Encrypted code registration
 <p>MB991223AC</p>	<p>MB991223 A: MB991219 B: MB991220 C: MB991221 D: MB991222 Harness set A: Test harness B: LED harness C: LED harness adapter D: Probe</p>	<p>MB991223</p>	<p>Making voltage and resistance measurements during troubleshooting A: Connect pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection</p>

REMOVAL AND INSTALLATION

M1543002100092



AC001260AB

1. ETACS-ECU
IMMOBILIZER-ECU REMOVAL STEPS
- FRONT FLOOR CONSOLE ASSEMBLY
(REFER TO GROUP 52A, FLOOR CONSOLE P.52A-9.)

>>A<<

2. IMMOBILIZER-ECU

<<A>>


IGNITION SWITCH REMOVAL STEPS

3. COLUMN COVER UPPER
4. COLUMN COVER LOWER
5. KEY RING ANTENNA
6. KEY REMINDER SWITCH
7. STEERING LOCK CYLINDER
8. IGNITION SWITCH

REMOVAL SERVICE POINT

<<A>>STEERING LOCK CYLINDER REMOVAL


1. Insert the key in the steering lock cylinder and turn it to the "ACC" position.
2. Using a small Phillips head screwdriver, pull the steering lock cylinder toward you.



INSTALLATION SERVICE POINT

>>A<< IMMOBILIZER-ECU INSTALLATION

If the immobilizer-ECU is replaced, peel off the immobilizer serial number sticker from shown position. Then attach a new immobilizer-ECU identification sticker in the same location.




INSPECTION

M1543002200088


IGNITION SWITCH CONTINUITY CHECK

Disconnect ignition switch connector C-87 without removing the ignition switch and steering lock cylinder. Then check the continuity.



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONNECTION
"LOCK" (OFF)	–	–
"ACC"	1 – 6	Less than two ohm
"ON"	1 – 2 – 4 – 6	Less than two ohm
"START"	1 – 2 – 3 – 5	Less than two ohm

KEY REMINDER SWITCH AND IGNITION KEY RING ANTENNA CONTINUITY CHECK



1. Ignition key reminder switch continuity check.
Disconnect key reminder switch connector C-88 without removing the ignition switch and steering lock cylinder. Then check the continuity.

STATUS OF IGNITION KEY	TESTER CONNECTION	SPECIFIED CONNECTION
Removed	4 – 6	Less than two ohm
Inserted	–	–

2. Ignition key ring antenna check.
Check the continuity between terminal 3 and terminal 7.
Standard value: two ohm or less

COMBINATION METERS ASSEMBLY AND VEHICLE SPEED SENSOR

INTRODUCTION

M1543009900260

INTRODUCTION TO COMBINATION METER DIAGNOSIS

All vehicles are equipped with an electrical speedometer and tachometer. If the speedometer or tachometer does not function, there may be trouble in the electrical system.

TROUBLESHOOTING STRATEGY

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a combination meter fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the symptom chart.
4. Verify the malfunction is eliminated.

M1543006900164

TROUBLE SYMPTOM CHART


M1543007200210

SYMPTOMS	INSPECTION PROCEDURE	REFERENCE PAGE
Speedometer does not work.	1	P.54A-30
Tachometer does not work.	2	P.54A-46
Fuel gauge does not work.	3	P.54A-53
Engine coolant temperature gauge does not work.	4	P.54A-58









SYMPTOM PROCEDURES


INSPECTION PROCEDURE 1: Speedometer does not work.

Speedometer Circuit



AC001222 AB





CIRCUIT OPERATION

- The ignition switch (IG1) circuit is the power source for the speedometer and vehicle speed sensor.
- The vehicle speed sensor is installed on the transaxle. Four pulses are generated with one turn of the vehicle speed sensor shaft. These pulse signals are sent into the speedometer. The speedometer calculates the pulse signals, and operates the indicator. At the same time, the travel distance is calculated.

TECHNICAL DESCRIPTION (COMMENT)

The cause may be a faulty vehicle speed sensor circuit system or a faulty speedometer. Vehicle speed sensor is also used by the engine control module (ECM) <M/T> or powertrain control module (PCM) <A/T>, auto-cruise control-ECU.

TROUBLESHOOTING HINTS

- Malfunction of the vehicle speed sensor
- Malfunction of the combination meter (printed-circuit board or speedometer and tachometer)
- Malfunction of the ECM <M/T> or PCM <A/T>
- Malfunction of the auto-cruise control-ECU
- Damaged harness wires or connectors


DIAGNOSIS

Required Special Tools:

- MB991223: Harness Set
- MB991502: Scan Tool (MUT-II)

⚠ CAUTION

To prevent damage to scan tool always turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting scan tool.



STEP 1. Check the vehicle speed sensor.

- (1) Connect scan tool MB991502 to the data link connector.
- (2) Turn the ignition switch to "ON" position.
- (3) Read the MFI system diagnostic trouble code.

Q: Is MFI system DTC P0500 output?

- YES** : Go to Step 12.
- NO** : Go to Step 2.

STEP 2. Check the odometer and trip odometer operation.

Q: Do the odometer and trip odometer work correctly?


- YES** : Go to Step 9.
- NO** : Go to Step 3.

STEP 3. Check the combination meter power supply circuit at the combination meter connector C-41.

- (1) Disconnect the combination meter connector C-41.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 52 and ground.

Q: Is the voltage 12 volts (battery positive voltage) between terminal 52 and ground?


- YES :** Go to Step 6.
NO : Go to Step 4.



STEP 4. Check the combination meter connector C-41 for damage.

Q: Is combination meter connector C-41 in good condition?

- YES :** Go to Step 5.
NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The speedometer should work normally.






STEP 5. Check the harness wires between combination meter connector C-41 and ignition switch (IG1).

NOTE: After checking junction block connectors C-101 and C-104, check the wires. If junction block connectors C-101 and C-104 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#).

Q: Is the harness wires between combination meter connector C-41 and ignition switch (IG1) in good condition?

- YES :** There is no action to be taken.
NO : Repair them. The speedometer should work normally.






STEP 6. Check the combination meter (speedometer) ground circuit at the combination meter connector C-42.

- (1) Disconnect the combination meter connector C-42.
- (2) Measure the resistance between terminal 34 and ground.

Q: Is the resistance value less than two ohm?

YES : Repair or repair the combination meter (printed-circuit board or speedometer and tachometer). The speedometer should work normally.

NO : Go to Step 7.




STEP 7. Check the combination meter connector C-42 for damage.

Q: Is combination meter connector C-42 in good condition?

YES : Go to Step 8.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.36-4. The speedometer should work normally.



STEP 8. Check the harness wire between combination meter connector C-42 and ground.

Q: Is the harness wire between combination meter connector C-42 and ground in good condition?

YES : There is no action to be taken.

NO : Repair it. The speedometer should work normally.


STEP 9. Check the combination meter vehicle speed sensor input signal circuit at the combination meter connector C-42.

- (1) Disconnect the combination meter connector C-42 and measure at the harness side.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 29 and ground.

Q: Is the voltage approximately 5 volts?

YES : Repair or repair the combination meter (printed-circuit board or speedometer and tachometer). The speedometer should work normally.

NO : Go to Step 10.




STEP 10. Check the combination meter connector C-42 for damage.





Q: Is combination meter connector C-42 in good condition?

YES : Go to Step 11.


NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The speedometer should work normally.



STEP 11. Check the harness wires between combination meter connector C-42 and vehicle speed sensor connector B-39.



CONNECTOR: C-77



AC003553 AH


NOTE: After checking intermediate connector C-28, B-36 <M/T> and joint connector C-77, check the wires. If intermediate connector C-28, B-36 <M/T> and joint connector C-77 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.52A-23.

Q: Are the harness wires between combination meter connector C-42 and vehicle speed sensor connector B-39 in good condition?

YES : There is no action to be taken.

NO : Repair them. The speedometer should work normally.

VEHICLE SPEED SENSOR
CONNECTOR B-39
(HARNESS SIDE)



AC002044 AC

STEP 12. Check the vehicle speed sensor power supply circuit at the vehicle speedometer connector B-39.


- (1) Disconnect the vehicle speed sensor connector B-39.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 1 and ground.

Q: Is the voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 15.

NO : Go to Step 13.

CONNECTOR: B-39 <2.4 L>



AC003550 AD


STEP 13. Check the vehicle speed sensor connector B-39 for damage.

Q: Is vehicle speed sensor connector B-39 in good condition?





YES : Go to Step 14.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-23. The speedometer should work normally.

CONNECTOR: B-39 <3.0 L>



AC003551 AD




STEP 14. Check the harness wires between vehicle speed sensor connector B-39 and ignition switch (IG1).

NOTE: After checking junction block connectors C-101 and C-104, joint connector C-78 and intermediate connector C-28, B-36 <MIT>, check the wires. If junction block connectors C-101 and C-104, joint connector C-78 and intermediate connector C-28, B-36 <MIT>, are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the harness wires between vehicle speed sensor connector B-39 and ignition switch (IG1) in good condition?

YES : There is no action to be taken.

NO : Repair them. The speedometer should work normally.




STEP 15. Check the vehicle speed sensor ground circuit at the vehicle speed sensor connector B-39.

- (1) Disconnect the vehicle speed sensor connector B-39.
- (2) Measure the resistance between terminal 2 and ground.

Q: Is the resistance less than two ohm?

YES : Go to Step 18.

NO : Go to Step 16.







STEP 16. Check the vehicle speed sensor connector B-39 for damage.

Q: Is vehicle speed connector B-39 in good condition?

YES : Go to Step 17.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The speedometer should work normally.






STEP 17. Check the harness wire between vehicle speed sensor connector B-39 and ground.

NOTE: After checking intermediate connector B-36 <M/T>, check the wires. If intermediate connector B-36 <M/T> is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Is the harness wire between vehicle speed sensor connector B-39 and ground in good condition?

YES : There is no action to be taken.

NO : Repair it. The speedometer should work normally.



STEP 18. Check the vehicle speed sensor signal circuit at the vehicle speed sensor connector B-39.





- (1) Disconnect the vehicle speed sensor connector B-39.
- (2) Turn the ignition switch to "ON"
- (3) Measure the voltage between terminal 3 and ground.

Q: Is the voltage approximately 9 volts or more?


More than approximately 9 volts : Replace the vehicle speed sensor. The speedometer should work normally.

Approximately 9 volts : Go to Step 19.

STEP 19. Check the vehicle speed sensor connector B-39, multi-center display connector C-09, auto-cruise control-ECU connector C-20 <vehicles with auto-cruise control>, ECM <M/T> or PCM <A/T> connector C-60 <2.4L-M/T>, C-57 <2.4L-A/T>, C-62 <3.0L-M/T> or C-59 <3.0L-A/T> and combination meter connector C-42.



CONNECTORS: C-57 <2.4L ENGINE-A/T>, C-59 <3.0L ENGINE-A/T>, C-60 <2.4L ENGINE-M/T>, C-62 <3.0L ENGINE-M/T>







Q: Are vehicle speed sensor connector B-39, multi-center display connector C-09, auto-cruise control-ECU connector C-20 <vehicles with auto-cruise control>, ECM <M/T> or PCM <A/T> connector C-60 <2.4L-M/T>, C-57 <2.4L-A/T>, C-62 <3.0L-M/T> or C-59 <3.0L-A/T> and combination meter connector C-42 in good condition?


YES : Go to Step 20.

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The speedometer should work normally.

STEP 20. Check the harness wires from vehicle speed sensor connector B-39, multi-center display connector C-09, auto-cruise control-ECU connector C-20 <vehicles with auto-cruise control>, ECM <M/T> or PCM <A/T> connector C-60 <2.4L-M/T>, C-57 <2.4L-A/T>, C-62 <3.0L-M/T> or C-59 <3.0L-A/T> and combination meter connector C-42.



CONNECTORS: C-57 <2.4L ENGINE-A/T>, C-59 <3.0L ENGINE-A/T>, C-60 <2.4L ENGINE-M/T>, C-62 <3.0L ENGINE-M/T>




NOTE: After checking joint connector C-77 and intermediate connector C-28, check the wires. If joint connector C-77 and intermediate connector C-28 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires from vehicle speed sensor connector B-39, multi-center display connector C-09, auto-cruise control-ECU connector C-20 <vehicles with auto-cruise control>, ECM <M/T> or PCM <A/T> connector C-60 <2.4L-M/T>, C-57 <2.4L-A/T>, C-62 <3.0L-M/T> or C-59 <3.0L-A/T> and combination meter connector C-42 in good condition?


YES : Go to Step 21.




NO : Repair them. The speedometer should work normally.

CONNECTOR: C-28



CONNECTOR: C-77





STEP 21. Check each equipment.

Disconnect multi-center display connector C-09, auto-cruise control-ECU connector C-20 <vehicles with auto-cruise control> and combination meter connector C-42 in that order one by one. Then check that MFI system DTC P0500 does not reset under any conditions.

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting scan tool MB991502.

- (1) Connect scan tool to the data link connector.
- (2) Turn the ignition switch to "ON" position.
- (3) Read the MFI system diagnostic trouble code.

Q: Does MFI system DTC P0500 reset when one of auto-cruise control-ECU or combination meter, ECM <M/T> or PCM <A/T> is disconnected?

YES : Go to Step 22.

NO : Replace the auto -cruise control-ECU, combination meter or ECM <M/T> or PCM <A/T> where applicable. The speedometer should work normally.

STEP 22. Recheck for malfunction.


Q: Is a malfunction eliminated?

YES : This diagnosis is complete. (If no malfunctions are not found in all steps, an intermittent malfunction is suspected. Refer to GROUP INTRDUCTION, How to Use Troubleshooting/Inspection Service Points – How to Cope with Intermittent Malfunction P.00-6.)

NO : Replace the speedometer.







INSPECTION PROCEDURE 2: Tachometer does not work.

Tachometer Circuit



W0S10M01A
AC004734AB

TSB Revision



CIRCUIT OPERATION

- The tachometer power is supplied from the ignition switch (IG1) circuit.
- For vehicles with 2.4L engine, the tachometer detects the ignition signal by the engine control module via the ignition failure sensor.
- For vehicles with 3.0L engine, the tachometer detects the ignition signal control via the distributor assembly.

TECHNICAL DESCRIPTION (COMMENT)

The ignition signal may not be sent from the engine, or there may be a malfunction in the power supply or ground circuit.

TROUBLESHOOTING HINTS

- Malfunction of the combination meter (printed circuit board or speedometer and tachometer)
- Damaged harness wires or connectors


DIAGNOSIS

Required Special Tools:

- MB991223: Harness Set
- MB991502: Scan Tool (MUT-II)

⚠ CAUTION

To prevent damage to scan tool MB991502, always turn the ignition switch to "LOCK" (OFF) position before connecting or disconnecting scan tool.



STEP 1. Check the vehicle speed sensor.

- (1) Connect scan tool MB991502 to the data link connector.
- (2) Turn the ignition switch to "ON" position.
- (3) Read the MFI system diagnostic trouble code.

Q: Is MFI system DTC P0300 output?

- YES** : Refer to GROUP 13A, Diagnosis [P.13A-20](#) and 13B, Diagnosis [P.13B-18](#).
- NO** : Go to Step 2.

STEP 2. Check the speedometer operation.

Q: Does the speedometer work normally?


- YES** : Refer to Inspection Procedure 1 [P.54A-30](#).
- NO** : Go to Step 3.

STEP 3. Check the combination meter (tachometer) ground circuit at the combination meter connector C-42.

- (1) Disconnect the combination meter connector C-42.
- (2) Measure the resistance between terminal 27 and ground.

Q: Is the resistance less than two ohm?


- YES** : Go to Step 6.
- NO** : Go to Step 4.




STEP 4. Check the combination meter connector C-42 for damage.

Q: Is combination meter connector C-42 in good condition?

- YES** : Go to Step 5.
- NO** : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The tachometer should work normally.






STEP 5. Check the harness wires between combination meter connector C-42 and ground.

Q: Is the harness wires between combination meter connector C-42 and ground in good condition?

YES : There is no action to be taken.

NO : Repair it. The tachometer should work normally.



STEP 6. Check the ignition signal input circuit at the combination meter connector C-42.

(1) Disconnect the combination meter connector C-42.

(2) Start the engine and run at idle.

(3) Measure the voltage between terminal 33 and ground.

Q: Is the voltage approximately 10 volts?

YES : Repair or repair the combination meter (printed-circuit board or speedometer and tachometer).





NO : Go to Step 7.

STEP 7. Check the ignition failure sensor connector B-03 <2.4L engine>, distributor assembly connector B-22 <3.0L engine>, automatic compressor controller connector C-13 <3.0L engine> and combination meter connector C-42 for damage.





Q: Are ignition failure sensor connector B-03 <2.4L engine>, distributor assembly connector B-22 <3.0L engine>, automatic compressor controller connector C-13 <3.0L engine> and combination meter connector C-42 in good condition?


YES : Go to Step 8.

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The tachometer should work normally.



STEP 8. Check the harness wires from combination meter connector C-42 to ignition failure sensor connector B-03 <2.4L engine>, distributor assembly connector B-22 <3.0L engine> and automatic compressor controller connector C-13 <3.0L engine>.





NOTE: After checking intermediate connector C-28, check the wires. If intermediate connector C-28 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.


Q: Are the harness wires from combination meter connector C-42 to ignition failure sensor connector B-03 <2.4L engine>, distributor assembly connector B-22 <3.0L engine> and automatic compressor controller connector C-13 <3.0L engine> in good condition?

YES : There is no action to be taken.





NO : Repair it. The tachometer should work normally.

INSPECTION PROCEDURE 3: Fuel gauge does not work.

Fuel Gauge Circuit



TSB Revision



CIRCUIT OPERATION

- The ignition switch (IG1) circuit is the power source for the fuel gauge.
- The resistance value fluctuates causing the circuit current to fluctuate when the fuel gauge unit the float moves up and down.
- The fuel gauge moves the needle by the circuit current.

TECHNICAL DESCRIPTION (COMMENT)

If the ignition switch (IG1) circuit is open, the gauge needle will not move at all. If the ground circuit is open, the gauge needle will move up to its extreme position.

TROUBLESHOOTING HINTS

- Malfunction of the fuel pump module (fuel gauge unit)
- Malfunction of the combination meter (printed-circuit board or fuel gauge assembly)

DIAGNOSIS

Required Special Tool:
MB991223: Harness Set

STEP 1. Check the speedometer operation.

Q: Does the speedometer work normally?

YES : Go to Step 2.

NO : Refer to Inspection Procedure 1 [P.52A-9](#).


STEP 2. Check the fuel pump module signal circuit at the fuel pump module connector D-17 by back probing.

- (1) Do not disconnect the fuel pump module connector D-17.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 2 and ground by back probing.

Q: Is the voltage approximately 5 volts or more?

YES : Go to Step 5.

NO : Go to Step 3.









STEP 3. Check the fuel pump module connector D-17 and combination meter connector C-41 for damage.

Q: Are fuel pump module connector D-17 and combination meter connector C-41 in good condition?

YES : Go to Step 4.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#). The fuel gauge should work normally.





STEP 4. Check the harness wires between fuel pump module connector D-17 and combination meter connector C-41.

NOTE: After checking intermediate connector C-90, check the wire. If intermediate connector C-90 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.36-4.

Q: Are the harness wires between fuel pump module connector D-17 and combination meter connector C-41 in good condition?

YES : Repair or replace the combination meter (printed-circuit board or fuel gauge assembly). The fuel gauge should work normally.

NO : Repair them. The fuel gauge should work normally.


STEP 5. Check the fuel pump module ground circuit at the fuel pump module connector D-17 by back probing.

- (1) Do not disconnect the fuel gauge unit connector D-17.
- (2) Measure the resistance between terminal 1 and ground by back probing.

Q: Is the resistance less than two ohm?

YES : Go to Step 8.

NO : Go to Step 6.




STEP 6. Check the fuel pump module connector D-17 for damage.

Q: Is fuel gauge unit connector D-17 in good condition?

YES : Go to Step 7.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The fuel gauge should work normally.




STEP 7. Check the harness wire between fuel pump module connector D-17 and ground.

Q: Is the harness wire between fuel pump module connector D-17 and ground in good condition?

YES : There is no action to be taken.

NO : Repair them. The fuel gauge should work normally.



STEP 8. Check the fuel gauge unit.

- (1) Remove the fuel pump module from the fuel tank. (Refer to GROUP 14C, Fuel Tank [P.52A-23](#).)
- (2) Check resistance value between terminals 2 and 1 is at standard value when the fuel gauge unit float is at point "F" (highest) and point "E" (lowest).
- (3) Check that the resistance value changes smoothly when the float moves slowly between point "F" (highest) and "E" (lowest).


Q: Is the resistance 3 – 5 ohms (at point "F") and 110 – 112 ohms (at point "E")?






YES : Repair or replace the combination meter (printed-circuit board or fuel gauge assembly). The fuel gauge should work normally.

NO : Replace the fuel gauge unit. The fuel gauge should work normally.

INSPECTION PROCEDURE 4: Engine coolant temperature gauge does not work.

Engine Coolant Temperature Gauge Circuit





CIRCUIT OPERATION

- The ignition switch (IG1) circuit is the power source for the engine coolant temperature gauge.
- Resistance value, which the engine coolant temperature gauge unit sends to the combination meter, is dependent on temperature of the engine coolant. This causes circuit current to fluctuate.

- The engine coolant temperature gauge moves the needle according to the circuit current.

TECHNICAL DESCRIPTION (COMMENT)

If the ignition switch (IG1) circuit is open, the gauge needle will not move at all. If the ground circuit is open, the gauge needle will move up to its extreme position.

TROUBLESHOOTING


- Malfunction of the engine coolant temperature gauge unit
- Malfunction of the combination meter (printed-circuit board or engine coolant temperature gauge assembly)
- Damaged harness wires or connectors

DIAGNOSIS

Required Special Tool:
MB991223: Harness Set

STEP 1. Check the speedometer operation.**Q: Does the speedometer work normally?****YES :** Go to Step 2.**NO :** Refer to Inspection Procedure 1 [P.52A-9](#).**STEP 2. Check the engine coolant temperature sensor signal circuit at the engine coolant temperature sensor connector B-08 by back probing.**

- (1) Do not disconnect the engine coolant temperature sensor connector B-08.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 1 and ground by back probing.




Q: Is the voltage approximately 9 volts or more?**YES :** Go to Step 5.**NO :** Go to Step 3.





STEP 3. Check the engine coolant temperature sensor connector B-08 and combination meter connector C-43 for damage.

Q: Are engine coolant temperature sensor connector B-08 and combination meter connector C-43 in good condition?

YES : Go to Step 4.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#). The engine coolant temperature gauge should work normally.





STEP 4. Check the harness wires between engine coolant temperature sensor connector B-08 and combination meter connector C-43.

NOTE: After checking intermediate connector C-28, check the wire. If intermediate connector C-28 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.36-4.


Q: Are the harness wires between engine coolant temperature sensor connector B-08 and combination meter connector C-43 in good condition?

YES : Repair or replace the combination meter (printed-circuit board or engine coolant temperature gauge assembly). The engine coolant temperature gauge should work normally.

NO : Repair them. The engine coolant temperature gauge should work normally.

STEP 5. Check the engine coolant temperature gauge unit.

- (1) Drain the engine coolant. (Refer to GROUP 00, Maintenance Service – Engine Coolant P.52A-9.)
- (2) Remove the engine coolant temperature gauge unit.
- (3) Immerse the unit in 78°C (150° F) water to measure the resistance.








Q: Is the resistance 104 ± 13.5 ohms?

- YES :** Repair or replace the combination meter (printed-circuit board or engine coolant temperature gauge assembly). The engine coolant temperature gauge should work normally.
- NO :** Replace the engine coolant temperature gauge unit. The engine coolant temperature gauge should work normally.

SPECIAL TOOLS

M1543000600251

TOOL	TOOL NUMBER AND NAME	SUPERSESSION	APPLICATION
 <p style="text-align: center;">B991502</p>	MB991502 Scan tool (MUT-II)	MB991496-OD	Reading MFI system diagnostic trouble code
<p>A</p>  <p>B</p>  <p>C</p>  <p>D</p>  <p style="text-align: center;">MB991223AC</p>	MB991223 A: MB991219 B: MB991220 C: MB991221 D: MB991222 Harness set A: Test harness B: LED harness C: LED harness adapter D: Probe	MB991223	Making voltage and resistance measurements during troubleshooting A: Connect pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection

ON-VEHICLE SERVICE

SPEEDOMETER CHECK



Adjust the pressure of tires to the specified level. (Refer to GROUP 31, On-vehicle Service P.31-6.)

M1543000900081

⚠ CAUTION

Do not operate the clutch suddenly. Do not increase/decrease speed rapidly while testing.

1. Set the vehicle onto a speedometer tester and use wheel chocks to hold the front wheels.
2. Set the vehicle onto a speedometer tester and use wheel chocks to hold the rear wheels.



3. To prevent the front wheel from moving from side to side, attach tension bars to the tie-down hook, and secure both ends to anchor plates.
4. To prevent the vehicle from moving, attach a chain or wire to the rear retraction hook, and make sure the end of the chain or wire is secured.
5. Check if the speedometer indicator range is within the standard values.

Standard value:

STANDARD INDICATION mph (km/h)	ALLOWANCE RANGE mph (km/h)
20 (32)	19 – 22 (31 – 35)
40 (64)	38 – 44 (61 – 71)
60 (97)	57 – 66 (92 – 106)
80 (129)	76 – 88 (122 – 142)
100 (161)	94 – 110 (151 – 177)

6. If not to the standard value, inspect for proper tire size. If not correct, replace the tires with original size tires and retest. If correct, replace the speedometer. If still not to standard value, replace the vehicle speed sensor.

TACHOMETER CHECK

M1543001000081


1. Attach an external high quality tachometer to the engine speed detection connector on the harness side (such as with a paper clip).

NOTE: For tachometer check, use an external high quality inductive tachometer.

2. Compare the readings of the vehicle tachometer and the external tachometer at every engine speed, and check if the variations are within the standard values.

Standard values:

- 700 r/min: ±100 r/min
- 3,000 r/min: ±150 r/min
- 5,000 r/min: ±250 r/min



- 6,000 r/min: ± 300 r/min

FUEL GAUGE UNIT CHECK

M1543001200085

Remove the fuel pump module and then remove the fuel gauge unit. (Refer to GROUP 13C, Fuel Tank P.13C-6.)

FUEL GAUGE UNIT RESISTANCE

1. Check that resistance value between the fuel gauge terminal and ground terminal is at the standard value when the fuel gauge unit float is between point "F" (highest) and point "E" (lowest).

Standard value:

- Point "F": 3 – 5 ohms
- Point "E": 110 – 112 ohms

2. Check that resistance value changes smoothly when the float moves slowly between point "F" (highest) and point "E" (lowest).
3. If all checks are correct, go to fuel gauge unit float height check. If any check is not correct, replace the fuel gauge unit.

FUEL GAUGE UNIT FLOAT HEIGHT

1. Move the float and measure height A at point "F" (highest) and B at point "E" (lowest) with the float arm touching stopper.

Standard value:

- A: 180.3 mm (7.10 inches)
- B: 18.8 mm (0.74 inch)




2. Adjust the float arm to the standard value, then go to the thermistor check.

THERMISTOR

⚠ CAUTION

After finishing this test, wipe the unit dry and install it in the fuel tank.

1. Connect the fuel gauge unit (thermistor) to the battery via a test light (12V – 3.4W). Immerse in water.
2. Condition is good if the light goes off when the thermistor is immersed in water and comes on when it is taken out of water.
3. If all check result are correct, the fuel gauge unit is OK. If either check result is not correct, replace the fuel gauge unit.





ENGINE COOLANT TEMPERATURE GAUGE UNIT CHECK

M1543001500086

1. Drain the engine coolant. (Refer to GROUP 00, Maintenance Service – Engine Coolant P.00-52.)
2. Remove the engine coolant temperature gauge unit.
3. Immerse the unit in 70°C (150°F) water to measure the resistance.

Standard value: 104 ± 13.5 ohms


4. If within the standard value, the sensor is OK. Reinstall it, then check the engine coolant temperature gauge (Refer to P.54A-68). If not within the standard value, replace it.



5. After checking, apply the 3M™ AAD Part No. 8731 or equivalent around the threads of the engine coolant temperature gauge unit.
6. Add engine coolant. (Refer to GROUP 00, Maintenance Service – Engine Coolant P.00E-2.)

COMBINATION METERS ASSEMBLY AND VEHICLE SPEED SENSOR REMOVAL AND INSTALLATION

M1543002900098



1. VEHICLE SPEED SENSOR


COMBINATION METER REMOVAL STEPS

2. METER HOOD ASSEMBLY (REFER TO GROUP 52A, INSTRUMENT PANEL P.52A-4.)
3. COMBINATION METER

VEHICLE SPEED SENSOR CHECK

M1543006400084

1. Remove the vehicle speed sensor and connect a 3 – 10 kohms resistor as shown in the illustration.
2. Turn the shaft of the vehicle speed sensor and check that there is voltage between terminals 2 – 3. (1 turn = 4 pulses)
3. If within the standard value, the vehicle speed sensor is OK. If not within the standard value, replace the vehicle speed sensor.



FUEL GAUGE RESISTANCE CHECK

M1543013300034

⚠ CAUTION


When inserting a testing probe into the power supply terminal, be careful not to touch the printed board.

1. Remove the power supply tightening screw.
2. Use an ohmmeter to measure the resistance value between the terminals.

Standard value:

- Power supply – Ground: Approximately 233 ohms
- Power supply – Fuel gauge: Approximately 108 ohms
- Fuel gauge – Ground: Approximately 125 ohms

3. If within the standard value, the fuel gauge is OK. If not within the standard value, replace the fuel gauge and engine coolant temperature gauge.



**ENGINE COOLANT TEMPERATURE GAUGE
RESISTANCE CHECK**

M1543013400031

CAUTION


When inserting a testing probe into the power supply terminal, be careful not to touch the printed board.

1. Remove the power supply tightening screw.
2. Use an ohmmeter to measure resistance value between the terminals.

Standard value:


- Power supply – Ground: Approximately 176 ohms
- Power supply – Engine coolant temperature gauge: Approximately 54 ohms
- Engine coolant temperature gauge – Ground: Approximately 230 ohms

3. If within the standard value, the engine coolant temperature gauge is OK.
4. If not within the standard value, replace the fuel gauge and engine coolant temperature gauge.



DISASSEMBLY AND ASSEMBLY

M1543003100084



AC001299AB

DISASSEMBLY STEPS

1. BULB AND SOCKET
2. BULB BRACKET
3. METER GLASS
4. METER PANEL
5. SPEEDOMETER AND TACHOMETER
6. TRIP COUNTER RESET KNOB

DISASSEMBLY STEPS (Continued)

7. FUEL GAUGE ASSEMBLY
8. ENGINE COOLANT TEMPERATURE GAUGE ASSEMBLY
9. PRINTED-CIRCUIT BOARD
10. METER CASE

TSB Revision

HEADLIGHT, FRONT SIDE MARKER LIGHT AND POSITION LIGHT ASSEMBLY

LIGHTING SYSTEM DIAGNOSIS

HEADLIGHT DIAGNOSIS

The headlights are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-9](#).

M1542010500155

ON-VEHICLE SERVICE

HEADLIGHT AIMING

M1542000900077


PRE-AIMING INSTRUCTIONS


1. Inspect for badly rusted or faulty headlight assemblies.
2. These conditions must be corrected before a satisfactory adjustment can be made.
3. Place the vehicle on a level floor.
4. Bounce the front suspension through three (3) oscillations by applying the body weight to hood or bumper.
5. Inspect tire inflation, and adjust if necessary.
6. Rock vehicle sideways to allow vehicle to assume its normal position.
7. If the fuel tank is not full, place a weight in luggage room of vehicle to simulate weight of a full tank [3 kg (6.5 pounds) per gallon.]
8. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 pounds) placed in driver's position.
9. Thoroughly clean headlight lenses.

AIMING WITH SCREEN OR WALL


Headlight Aim Preparation

1. Set the distance between the screen and the bulb center marks of the headlight as shown in the illustration.





2. Four lines of adhesive tape (or equivalent markings) are required on screen or wall:
 - (1) Position a vertical tape or mark so that it is aligned with the vehicle center line.
 - (2) Position a horizontal tape or mark with reference to center line of headlight bulb.
 - (3) Position a vertical tape or mark on the screen with reference to the center line of each headlight bulb.



Visual Headlight Adjustment

1. A properly aiming low-beam will on the aiming screen 3m (9.8 feet) in front the vehicle. The shaded area as shown in the illustration indicates high intensity zone.

NOTE: 3m (9.8feet) in front of the vehicle must be the distance measured from the headlight center mark.

Standard value:

(Vertical direction) 21mm (0.8 inch) below horizontal (H)

(Horizontal direction) Position where the 15 degree angle sloping section intersects the vertical line (V)


2. When adjusting headlight, disconnect the other headlight harness.

⚠ CAUTION

Do not a headlight for more than three minutes or the plastic headlight lens will be deformed.


3. Turn the adjusting screws, adjust low-beam of the headlights to match the specified pattern on the aiming screen.

NOTE: If the visual low-beam headlight adjustment is made, high beam adjustment is not necessary.



Vertical Adjusting

1. Turn the adjusting screw so that the low-beam axis meets the standard value.
2. Check to see if the light distribution projected on the aiming screen is the same as the light distribution pattern described in Visual Headlight Adjustment.
3. If the differ, turn the vertical adjusting screw to adjust the vertical angle until the light distribution coincides with the correct lighting pattern.



Horizontal Adjusting

1. Check to see if the light distribution projected on the aiming screen is the same as the light distribution pattern described in Visual Headlight Adjustment.
2. If they differ, turn the horizontal adjusting screw to adjust the horizontal angle until the light distribution coincides with the correct lighting pattern.

INTENSITY MEASUREMENT

M1542001000077

$I = Er^2$ Where:

- I = intensity (cd)
- E = illumination (lux)
- r = distance (m) from headlights to illuminometer


Using a photometer, and following its manufacturer's instruction manual, measure the headlight intensity and check to be sure that the limit value is satisfied.

Limit: 20,000 cd or more

NOTE: When measuring the intensity, maintain an engine speed of 2,000 r/min, with the battery fully charged.

There may be special local regulations pertaining to headlight intensity. Be sure to make any adjustments necessary to satisfy such regulations.


If an illuminometer is used to make the measurements, convert its values to photometer values by using the following formula.

BULB REPLACEMENT

1. Disconnect the connector.
2. Remove the sealing cover.

⚠ CAUTION

Do not touch the surface of the bulb with hands or dirty gloves as the bulb may pop after a short time. If the surface does become dirty, clean it with alcohol or thinner, and let it dry thoroughly before installing.



3. Unhook the spring securing the bulb, and then remove the bulb.

⚠ CAUTION

Do not touch the surface of the bulb with hands or dirty gloves as the bulb may pop after a short time. If the surface does become dirty, clean it with alcohol, and let it dry thoroughly before installing.

4. Install the spring and sealing cover securely after the bulb replacement, or the lens will be out of focus, or water will get inside the light unit.

HEADLIGHT

REMOVAL AND INSTALLATION



M1542002700079

⚠ WARNING

- Before removal of the air bag module, refer to **GROUP 52B, SRS Service Precautions and Air Bag Module and Clock Spring P.52B-15.**
- When removing and installing the steering wheel, do not let it bump against the air bag module.

Post-installation operation

Headlight aiming adjustment (Refer to [P.54A-69.](#))




AC001307AB

1. ETACS-ECU
2. FRONT-ECU
3. COLUMN SWITCH (REFER TO GROUP 37, STEERING WHEEL AND SHAFT [P.37A-20.](#))

4. HEADLIGHT ASSEMBLY

HEADLIGHT RELAY (LOW), (HIGH) CHECK

M1542008200061



BATTERY VOLTAGE	TERMINAL NO. TO BE CONNECTED TO BATTERY	TERMINAL NO. TO PERFORM CONTINUITY TEST
Supplied	1 – 3	4 – 5
Not supplied	–	1 – 3

FOG LIGHT

FOG LIGHT DIAGNOSIS


The fog lights are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-6](#).

ON-VEHICLE SERVICE


FOG LIGHT AIMING

M1542001100074


1. Inspect for badly rusted or faulty fog light assemblies.
2. These conditions must be corrected before a satisfactory adjustment can be made.
3. Place the vehicle on a level floor.
4. Bounce the front suspension through three (3) oscillations by applying the body weight to the hood or bumper.
5. Inspect tire inflation, and adjust if necessary.
6. Rock the vehicle sideways to allow the vehicle to assume its normal position.
7. If fuel tank is not full, place a weight in the luggage room of the vehicle to simulate weight of a full tank [3 kg (6.5 pounds) per gallon.]
8. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 pounds) placed in driver's position.
9. Thoroughly clean the fog light lenses.



10. Measure the center of the fog lights as shown in the illustration.



11. Set the distance between the screen and the center of the fog lights as shown in the illustration.




12. Check if the beam shining onto the screen is at the standard value.

Standard value:



- **(Vertical direction): 151 mm (5.9 inches) below horizontal (H)**
- **(Horizontal direction): Parallel to direction of vehicle travel**

NOTE: The horizontal direction is non-adjustable. If deviation of the light beam axis exceeds the standard value, check that the mounting location or some other points are not faulty.



**FOG LIGHT
REMOVAL AND INSTALLATION**

M1542001500113



AC001313 AB

- 1. ETACS-ECU
- 2. FRONT-ECU
- 3. FOG LIGHT SWITCH


- FOG LIGHT REMOVAL STEPS**
- 4. FOG LIGHT ASSEMBLY
 - 5. SEAL PLATE
 - 6. FOG LIGHT COVER
 - 7. FOG LIGHT CONNECTOR COVER
 - 8. FOG LIGHT BULB

<<A>>

REMOVAL SERVICE POINT

<<A>>FOG LIGHT BULB REMOVAL


Unhook the spring securing the bulb, and then remove the bulb.



AC001314AB

FOG LIGHT SWITCH CONTINUITY CHECK


M1542007400073



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Pressed	2 – 5 (Illumination light) 6 – 7(Switch)	Less than two ohm
Released	2 – 5 (Illumination light)	Less than two ohm

FRONT FOG LIGHT RELAY CHECK

M1542007500081



BATTERY VOLTAGE	TERMINAL NO. TO BE CONNECTED TO BATTERY	TERMINAL NO. TO PERFORM CONTINUITY TEST
Supplied	1 – 3	4 – 5
Not supplied	–	1 – 3

FRONT COMBINATION LIGHT

FRONT COMBINATION LIGHT DIAGNOSIS

M1542000700385





The taillights (position light) and turn-signal lights are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-9](#).

REMOVAL AND INSTALLATION

M1542009500032

⚠ WARNING

- Before removal of the air bag module, refer to GROUP 52B, SRS Service Precautions and Air Bag Module and Clock Spring [P.52B-15](#).
- When removing and installing the steering wheel, do not let it bump against the air bag module.



AC001321 AB


1. ETACS-ECU
2. FRONT-ECU
3. COLUMN SWITCH (REFER TO GROUP 37, STEERING WHEEL AND SHAFT [P.37A-20](#).)

**FRONT COMBINATION LIGHT
REMOVAL STEPS**

4. FRONT COMBINATION LIGHT ASSEMBLY
5. SOCKET
6. BULB

TAILLIGHT RELAY CHECK

M1542007800037



BATTERY VOLTAGE	TERMINAL NO. TO BE CONNECTED TO BATTERY	TERMINAL NO. TO PERFORM CONTINUITY TEST
Supplied	1 – 3	4 – 5
Not supplied	–	1 – 3

REAR COMBINATION LIGHT

LIGHTING SYSTEM DIAGNOSIS

M1542000700244





The taillights and turn-signal lights are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 52B, SWS Diagnosis [P.54B-9](#).

REAR COMBINATION LIGHT REMOVAL AND INSTALLATION

M1542003900117

⚠ WARNING

- Before removal of the air bag module, refer to GROUP 52B, SRS Service Precautions and Air Bag Module and Clock Spring [P.52B-15](#).
- When removing and installing the steering wheel, do not let it bump against the air bag module.



1. ETACS-ECU
2. FRONT-ECU
3. COLUMN SWITCH (REFER TO GROUP 37, STEERING WHEEL AND SHAFT [P.37A-20](#).)

REAR COMBINATION LIGHT REMOVAL STEPS

- LID FLOOR CARPET ASSEMBLY <ECLIPSE> (REFER TO GROUP 52A, TRIMS [P.52A-10](#).)
- TRUNK ROOM TRIM <ECLIPSE SPYDER> (REFER TO GROUP 52A, TRIMS [P.52A-10](#).)
- 4. REAR COMBINATION LIGHT
- 5. HARNESS ASSEMBLY
- 6. BULB

BACK-UP LIGHT

BACKUP LIGHT DIAGNOSIS

M1542000700396





The taillights (position lights) are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-9](#).

REMOVAL AND INSTALLATION

M1542005700067

⚠ WARNING

- Before removal of the air bag module, refer to GROUP 52B, SRS Service Precautions and Air Bag Module and Clock Spring [P.52B-15](#).
- When removing and installing the steering wheel, do not let it bump against the air bag module.



1. ETACS-ECU
2. FRONT-ECU
3. COLUMN SWITCH (REFER TO GROUP 37, STEERING WHEEL AND SHAFT [P.37A-20](#).)

- REMOVAL STEPS**
4. BACKUP LIGHT ASSEMBLY
 5. SOCKET
 6. BULB

AC004326AB

DOME LIGHT


DOME LIGHT DIAGNOSIS

The dome light is controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-6](#).

HIGH-MOUNTED STOPLIGHT

REMOVAL AND INSTALLATION

M1542005100098




- REMOVAL STEPS**
- LIFTGATE TRIM <ECLIPSE>
(REFR TO GROUP 42, LIFGTGATE-
LIFTGATE TRIM [P.52A-10.](#))
1. HIGH-MOUNTED STOPLIGHT

- REMOVAL STEPS (Continued)**
2. SOCKET SEMI ASSEMBLY
 3. BULB

RHEOSTAT

REMOVAL AND INSTALLATION

M1542006000072



AC001326 AC


RHEOSTAT REMOVAL STEPS

1. METER HOOD ASSEMBLY (REFER TO GROUP 52A, INSTRUMENT PANEL P.52A-4.)
2. RHEOSTAT

INSPECTION

M1542006100079

1. Connect the battery and the test bulb (40 W) as shown in the illumination.
2. Operate the rheostat, and if brightness changes smoothly without switching off, rheostat function is normal.



AC001327AB

HAZARD WARNING LIGHT SWITCH

HAZARD WARNING LIGHT SWITCH DIAGNOSIS


M1542000700255

The hazard warning lights are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-9](#).

HAZARD WARNING LIGHT SWITCH

REMOVAL AND INSTALLATION

M1542006600104



AC004505AB

1. ETACS-ECU


HAZARD WARNING LGHT SWITCH REMOVAL STEPS

2. CENTER PANEL ASSEMBLY (REFER TO GROUP 52A, INSTRUMENT PANEL [P.52A-4](#).)
3. HAZARD WARNING LIGHT SWITCH

INSPECTION

M1542006700093

HAZARD WARNING LIGHT SWITCH CONTINUITY CHECK




AC001329AB

SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
Released	3 – 4 (Illumination)	Less than two ohm
Pressed	1 – 2 (Switch) 3 – 4 (Illumination)	Less than two ohm

COLUMN SWITCH**REMOVAL AND INSTALLATION**

M1543009100145



AC001330AD

REMOVAL STEPS


1. COLUMN COVER UPPER
2. COLUMN COVER LOWER

REMOVAL STEPS (Continued)

3. TURN-SIGNAL AND LIGHTING SWITCH
4. WINDSHIELD WIPER AND WINDSHIELD WASHER SWITCH


INSPECTION

TURN-SIGNAL AND LIGHTING SWITCH CHECK



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
OFF	–	Open circuit
Taillight switch ON	5 – 9	Less than two ohms
Headlight switch ON	5 – 7 – 9	Less than two ohms
Passing switch ON	2 – 12	Less than two ohms
Dimmer switch ON	2 – 11 – 12	Less than two ohms
Turn-signal light switch (LH) ON	1 – 2	Less than two ohms
Turn-signal light switch (RH) ON	2 – 3	Less than two ohms


WINDSHIELD WIPER AND WINDSHIELD WASHER SWITCH CHECK <ECLIPSE>



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
OFF	–	Open circuit
Windshield wiper mist switch ON	23 – 32	Less than two ohms
Windshield intermittent wiper switch ON	23 – 31	Less than two ohms
Windshield low-speed wiper switch ON	23 – 30	Less than two ohms
Windshield high-speed wiper switch ON	21 – 23	Less than two ohms
Windshield washer switch ON	22 – 23	Less than two ohms
Rear intermittent wiper switch ON	25 – 26	Less than two ohms
Rear washer switch ON	25 – 29	Less than two ohms

Measure the resistance value at terminal numbers 27 and 28. The resistance value should rise smoothly from approximately less than 2 ohms ("FAST" position) to approximately 1 k Ω ("SLOW" position).

WINDSHIELD WIPER AND WINDSHIELD WASHER SWITCH CHECK <ECLIPSE SPYDER>



SWITCH POSITION	TESTER CONNECTION	SPECIFIED CONDITION
OFF	–	Open circuit
Windshield wiper mist switch ON	23 – 32	Less than two ohms
Windshield intermittent wiper switch ON	23 – 31	Less than two ohms
Windshield low-speed wiper switch ON	23 – 30	Less than two ohms
Windshield high-speed wiper switch ON	21 – 23	Less than two ohms
Windshield washer switch ON	22 – 23	Less than two ohms

Measure the resistance value at terminal numbers 27 and 28. The resistance value should rise smoothly from approximately less than 2 ohms ("FAST" position) to approximately 1 k Ω ("SLOW" position).

HORN

HORN DIAGNOSIS <VEHICLE WITH KEYLESS ENTRY SYSTEM OR THEFT ALARM SYSTEM>


M1543000700270

The keyless entry system horn answerback and theft-alarm system are controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis [P.54B-9](#).

HORN

REMOVAL AND INSTALLATION

M1543007900134



AC001334 AB

REMOVAL STEPS

- AIR CLEANER (REFER TO GROUP 15, AIR CLEANER [P.15-5](#).)


REMOVAL STEPS (Continued)

1. HORN (FOR KEYLESS ENTRY SYSTEM OR THEFT ALARM SYSTEM)
2. HORN (STANDARD TYPE)

INSPECTION

M1543008000101

HORN RELAY, THEFT-ALARM HORN RELAY
CONTINUITY CHECK





BATTERY VOLTAGE	TERMINAL NO. TO BE CONNECTED TO BATTERY	SPECIFIED CONDITION
Supplied	1 – 3	4 – 5
Not supplied	–	1 – 3

CIGARETTE LIGHTER, ACCESSORY SOCKET

REMOVAL AND INSTALLATION

M1543013500038



CIGARETTE LIGHTER REMOVAL
STEPS

1. FLOOR CONSOLE ASSEMBLY (REFER TO GROUP 52A, FLOOR CONSOLE P.52A-9.)
2. PLUG

CIGARETTE LIGHTER REMOVAL
STEPS (Continued)

3. NUT
4. CASE
5. SOCKET

AC001337 AB


**ACCESSORY SOCKET REMOVAL
STEPS**

6. CONSOLE BOX ASSEMBLY (REFER TO GROUP 52A, FLOOR CONSOLE P.52A-9.)
7. CASE
8. SOCKET

CIGARETTE LIGHTER INSPECTION

M1543005700112

- Take out the plug, and check for a worn edge on the element spot connection, and for shreds of tobacco or other material on the element.
- Using an ohmmeter, check that the element resistance value is 1.7 ohms.



RADIO AND TAPE PLAYER

**RADIO WITH TAPE PLAYER AND CD PLAYER, SPEAKER AND ANTENNA
DIAGNOSIS**

M1543009900282

**INTRODUCTION TO AUDIO SYSTEM
DIAGNOSIS**

The diagnosis for symptoms such as noise being emitted, no sound being played, or sound coming only out of one side while listening to the audio system or tape is provided.

TROUBLESHOOTING STRATEGY

M1544004800108

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find audio system fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.

3. Find the malfunction by following the Symptom Chart.

4. Verify malfunction is eliminated.

TROUBLE SYMPTOM CHART


SYMPTOMS		INSPECTION PROCEDURE	REFERENCE PAGE
When power switch is turned "ON," no power is available.		1	P.54A-94
No sound. <vehicles with amplifier>		2	P.54A-98
No sound from one speaker.		3	P.54A-103
Separate type CD player does not operate.		4	P.54A-140
The multi-center display dose not display the information concerning the audio system correctly.		5	P.54A-103
Sound volume is not changed if the vehicle speed is changed <Vehicles with amplifier>.		6	P.54A-140
Noise	Noise appears at certain places when traveling (AM).	7	P.54A-144
	Noise appears at certain places when traveling (FM).	8	P.54A-145
	Mixed with noise, only at night (AM).	9	P.54A-146
	Broadcasts can be heard but both AM and FM have a lot of noise.	10	P.54A-147
	There is more noise on either AM or FM.	11	P.54A-148
	There is noise when starting the engine.	12	P.54A-150
	Some noise appears when there is vibration or shocks during traveling.	13	P.54A-152
	Noise sometimes appears on FM during traveling.	14	P.54A-153
	Ever-present noise.	15	P.54A-154
Radio	There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.	16	P.54A-154
	Poor reception.	17	P.54A-154
	Distortion on AM or on both AM and FM.	18	P.54A-155
	Distortion on FM only.	19	P.54A-156
	Using the auto select function, too few automatic stations are selected.	20	P.54A-156
	Preset stations are erased.	21	P.54A-158
Tape player	Cassette tape can not be inserted.	22	P.54A-154
	Sound quality is poor, or sound is weak.	23	P.54A-154
	Cassette tape can not be ejected.	24	P.54A-155
	Uneven revolution. tape speed is fast or slow.	25	P.54A-156
	Automatic search does not work.	26	P.54A-156
	Malfunction of the auto reverse.	27	P.54A-158
	Tape gets caught in mechanism.	28	P.54A-154




SYMPTOMS		INSPECTION PROCEDURE	REFERENCE PAGE
CD player, CD auto changer	CD can not be inserted.	29	P.54A-164
	No sound (CD only).	30	P.54A-164
	CD sound skips.	31	P.54A-165
	Sound quality is poor.	32	P.54A-165
	CD cannot be ejected.	33	P.54A-165
Motor antenna	Motor antenna won't extend or retract	34	P.54A-166
	Motor antenna extends and retracts but does not receive radio signal	35	P.54A-175

SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: When Power Switch is Turned "ON," No Power is Available.

Radio, Tape Player, CD Player and CD Auto Changer





CIRCUIT OPERATION

Power is supplied to the radio and CD player when the ignition switch is at the "ACC" or "ON" position.

TECHNICAL DESCRIPTION (COMMENT)

The cause is probably a faulty radio and CD player power supply circuit system.

TROUBLESHOOTING HINTS

- Damaged harness wire or connector.
- Malfunction of the radio and CD player.

DIAGNOSIS

Required Special Tool:

- MB991223: Harness set


STEP 1. Check the radio and CD play power supply circuit by backprobing.


- (1) Do not disconnect radio, tape player, CD player and CD auto changer connector C-22.
- (2) Turn the ignition switch to "ACC" position.
- (3) Measure the voltage between terminal 10 and ground by backprobing.

Q: Is the voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 4.

NO : Go to Step 2.






STEP 2. Check radio, tape player, CD player and CD auto changer connector C-22 for damage.

Q: Are radio, tape player, CD player and CD auto changer connector C-22 in good condition?


YES : Go to Step 3.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.54B-9](#). If the power switch is turned on, the radio, tape player, CD player and CD auto changer should operate normally.



STEP 3. Check the harness wires between radio, tape player, CD player and CD auto changer connector C-22 and ignition switch (ACC).


NOTE: After inspecting intermediate connector C-89 and junction block connectors C-101 and C-109, inspect the wire. If intermediate connector C-89 and junction block connectors C-101 and C-109 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.54B-9](#).



Q: Are the harness wires between radio, tape player, CD player and CD auto changer connector C-22 and ignition switch (ACC) in good condition?

YES : There is no action to be taken.

NO : Repair them. If the power switch is turned on, the radio and CD player should operate normally.



STEP 4. Are the radio, tape player, CD player and CD auto changer installed correctly?

NOTE: The radio, tape player, CD player and CD auto changer are grounded to the instrument panel center reinforcement directly.




Q: Are the radio, tape player, CD player and CD auto changer installed correctly?


YES : Repair or replace the radio, tape player, CD player and CD auto changer. If the power switch is turned on, the radio, tape player, CD player and CD auto changer should operate normally.

NO : Install properly. If the power switch is turned on, the radio, tape player, CD player and CD auto changer should operate normally.

INSPECTION PROCEDURE 2: No sound. <vehicles with amplifier>

Amplifier Power Supply Circuit





CIRCUIT OPERATION

Power is supplied to the amplifier when the fusible link (4).

TECHNICAL DESCRIPTION (COMMENT)

The cause is probably a faulty amplifier power supply circuit system.

TROUBLESHOOTING HINTS

- Damaged harness wire or connector.
- Damaged DIN cable.
- Malfunction of the amplifier.
- Malfunction of the radio and tape player.

DIAGNOSIS

Required Special Tool:

- MB991223: Harness set


STEP 1. Check the amplifier power supply circuit by backprobing.



- (1) Do not disconnect amplifier connector D-20.
- (2) Measure the voltages between terminal 2 and ground by backprobing.
- (3) Measure the voltage between terminal 10 and ground by backprobing.


Q: Are the voltages approximately 12 volts (battery positive voltage)?

YES : Go to Step 4.

NO : Go to Step 2.






**STEP 2. Check amplifier connector D-20 for damage.****Q: Is amplifier connector D-20 in good condition?****YES :** Go to Step 3.**NO :** Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The speakers should sound.



STEP 3. Check the harness wires between amplifier connector D-20 and fusible link (4).



NOTE: After inspecting intermediate connector C-89, inspect the wires. If intermediate connector C-89 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.



Q: Are the harness wires between amplifier connector D-20 and fusible link (4) in good condition?

YES : There is no action to be taken.



NO : Repair them. The speakers should sound.

**STEP 4. Check amplifier connector D-20 for damage.**

Q: Is amplifier connector D-20 in good condition?

YES : Go to Step 5 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The speakers should sound.

**STEP 5. Check the harness wires between amplifier connector D-20 and ground.**

Q: Are the harness wires between amplifier connector D-20 and ground in good condition?

YES : Go to Step 6 .

NO : Repair them. The speakers should sound.

STEP 6. Check the DIN cable between amplifier and radio, tape player, CD player and CD auto changer.

Q: Are the DIN cable in good condition?


YES : Repair or replace the amplifier or radio, tape player, CD player and CD auto changer. The speakers should sound.

NO : Repair or replace it. The speakers should sound.

M1544005700074

INSPECTION PROCEDURE 3: No Sound from One Speaker.


Speaker System Circuit <Vehicles Without Amplifier>



NOTE
*1: ECLIPSE
*2: ECLIPSE SPYDER








W1S11M01AA
AC004632AB

Speaker System Circuit <Vehicles With Amplifier>



NOTE
*1: ECLIPSE
*2: ECLIPSE SPYDER

W1S11M02AA
AC004630AB



CIRCUIT OPERATION

- <Vehicles without amplifier>
- The sound is heard from the speaker according to audio signal output from the radio and CD player.
- <Vehicles with amplifier>

- The sound signals are sent from the radio, and CD player into the amplifier. After the signals are amplified and filtered, the sound signals are sent to the speaker.

TECHNICAL DESCRIPTION (COMMENT)

The cause is probably a faulty speaker circuit system.

TROUBLESHOOTING HINTS

- Malfunction of the speaker.

TSB Revision

- Damaged harness wire or connector.
- Malfunction of the radio and CD player.
- Malfunction of the amplifier <vehicles with amplifier>.
- Malfunction of the DIN cable <vehicles with amplifier>.

DIAGNOSIS

STEP 1A. Check which speaker has no sound on the vehicles without amplifier?

- (1) Use the speaker test to determine which speaker does not sound.

Q: Which speaker has no sound on the vehicles without amplifier?

Front Door speaker (LH) : Go to Step 2 .

Front Door speaker (RH) : Go to Step 5 .

Rear speaker (LH) : Go to Step 8 .

Rear speaker (RH) : Go to Step 11 .

Tweeter (LH) : Go to Step 14 .

Tweeter (RH) : Go to Step 17 .

STEP 1B. Check which speaker has no sound on the vehicles with amplifier?

- (1) Use the speaker test to determine which speaker does not sound.

Q: Which speaker has no sound on the vehicles with amplifier?

Front Door speaker (LH) : Go to Step 20.

Front Door speaker (RH) : Go to Step 24 .

Rear speaker (LH) : Go to Step 28 .

Rear speaker (RH) : Go to Step 32 .

Woofer : Go to Step 36 .

Tweeter (LH) : Go to Step 40 .

Tweeter (RH) : Go to Step 44 .


STEP 2. Check the Front door speaker (LH).

- (1) Remove the front door speaker (LH).
 (2) Check that the front door speaker (LH) generates noise when a five-volt voltage is applied on the front door speaker (LH) terminal.

Q: Is the front door speaker (LH) generating noise?

YES : Go to Step 3 .

NO : Replace the front door speaker (LH). The front door speaker (LH) should sound.









STEP 3. Check front door speaker (LH) connector E-10 and radio and CD player connector C-22 for damage.

Q: Are harness connectors E-10 and C-22 in good condition?

YES : Go to Step 4 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The door speaker (LH) should sound.





STEP 4. Check the harness wires between front door speaker (LH) connector E-10 and radio and CD player connector C-22.

NOTE: After inspecting intermediate connector C-91, inspect the wire. If intermediate connector C-91 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-23.

Q: Are the harness wires between front door speaker (LH) connector E-10 and radio and CD player connector C-22 in good condition?

YES : Repair or replace the radio and CD player. The front door speaker (LH) should sound.

NO : Repair them. The front door speaker (LH) should sound.

STEP 5. Check the front door speaker (RH).

- (1) Remove the front door speaker (RH).
- (2) Check that the front door speaker (RH) generates noise when a five-volt voltage is applied on the front door speaker (RH) terminal.

Q: Is the front door speaker (RH) generating noise?

YES : Go to Step 6 .



NO : Replace the front door speaker (RH). The front door speaker (RH) should sound.





STEP 6. Check front door speaker (RH) connector E-01 and radio and CD player connector C-22 for damage.

Q: Are harness connectors E-01 and C-22 in good condition?

YES : Go to Step 7 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.36-4](#). The front door speaker (RH) should sound.





STEP 7. Check the harness wires between front door speaker (RH) connector E-01 and radio and CD player connector C-22.

NOTE: After inspecting intermediate connector C-95, inspect the wire. If intermediate connector C-95 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-9.

Q: Are the harness wires between front door speaker (RH) connector E-01 and radio and CD player connector C-22 in good condition?

YES : Repair or replace the radio and CD player. The front door speaker (RH) should sound.

NO : Repair them. The front door speaker (RH) should sound.

STEP 8. Check the rear speaker (LH).

- (1) Remove the rear speaker (LH).
- (2) Check that the rear speaker (LH) generates noise when a five-volt voltage is applied on the rear speaker (LH) terminal.

Q: Is the rear speaker (LH) generating noise?

YES : Go to Step 9 .




NO : Replace the rear speaker (LH). The rear speaker (LH) should sound.





STEP 9. Check rear speaker (LH) connector F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and radio and CD player connector C-22 for damage.

Q: Are harness connectors F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and C-22 in good condition?

YES : Go to Step 10 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#). The rear speaker (LH) should sound.





STEP 10. Check the harness wires between rear speaker (LH) connector F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and radio and CD player connector C-22.

NOTE: After inspecting intermediate connector C-90, inspect the wire. If intermediate connector C-90 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between the rear speaker (LH) connector F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and radio and CD player connector C-22 in good condition?

YES : Repair or replace the radio and CD player. The rear speaker (LH) should sound.

NO : Repair them. The rear speaker (LH) should sound.


STEP 11. Check the rear speaker (RH).

- (1) Remove the rear speaker (RH).
- (2) Check that the rear speaker (RH) generates noise when a five-volt voltage is applied on the rear speaker (RH) terminal.

Q: Is the rear speaker (RH) generating noise?

YES : Go to Step 12 .

NO : Replace the rear speaker (RH). The rear speaker (RH) should sound.










STEP 12. Check rear speaker (RH) connector F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and radio and CD player connector C-22 for damage.

Q: Are harness connectors F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and C-22 in good condition?

YES : Go to Step 13 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The rear speaker (RH) should sound.






STEP 13. Check the harness wires between rear speaker (RH) connector F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and radio and CD player connector C-22.

NOTE: After inspecting intermediate connector C-90 inspect the wire. If intermediate connector C-90 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between rear speaker (RH) connector F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and radio and CD player connector C-22 in good condition?

YES : Repair or replace the radio and CD player. The rear speaker (RH) should sound.

NO : Repair them. The rear speaker (RH) should sound.




STEP 14. Check the tweeter (LH).

- (1) Remove the tweeter (LH).
- (2) Check that the tweeter (LH) generates noise when a five-volt voltage is applied on the tweeter (LH) terminal.

Q: Is the tweeter (LH) generating noise?

YES : Go to Step 15 .

NO : Replace the tweeter (LH). The tweeter (LH) should sound.








STEP 15 Check tweeter (LH) connector E-08 and radio and CD player connector C-22 for damage.

Q: Are harness connectors E-08 and c-22 in good condition?

YES : Go to Step 16 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The tweeter (LH) should sound.





STEP 16. Check the harness wires between tweeter (LH) connector E-08 and radio and CD player connector C-22.
NOTE: After inspecting intermediate connector C-91, inspect the wire. If intermediate connector C-91 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between tweeter (LH) connector E-08 and radio and CD player connector C-22 in good condition?

YES : Repair or replace the radio and CD player. The tweeter (LH) should sound.

NO : Repair them. The tweeter (LH) should sound.

STEP 17. Check the tweeter (RH).

- (1) Remove the tweeter (RH).
- (2) Check that the tweeter (RH) generates noise when a five-volt voltage is applied on the speaker terminal.

Q: Is the tweeter (RH) generating noise?

YES : Go to Step 18 .



NO : Replace the tweeter (RH). The tweeter (RH) should sound.





STEP 18. Check tweeter (RH) connector E-03 and radio and CD player connector C-22 for damage.

Q: Are harness connectors E-03 and C-22 in good condition?

YES : Go to Step 19 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The tweeter (RH) should sound.





STEP 19. Check the harness wires between tweeter (RH) connector E-03 and radio and CD player connector C-22.
NOTE: After inspecting intermediate connector C-95, inspect the wire. If intermediate connector C-95 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between tweeter (RH) connector E-03 and radio and CD player connector C-2 in good condition?

YES : Repair or replace the radio and CD player. The tweeter (RH) should sound.

NO : Repair them. The tweeter (RH) should sound.

STEP 20. Check the front door speaker (LH).

- (1) Remove the front door speaker (LH).
- (2) Check that the front door speaker (LH) generates noise when a five-volt voltage is applied on the front door speaker (LH) terminal.

Q: Is the front door speaker (LH) generating noise?

YES : Go to Step 21 .




NO : Replace the front door speaker (LH). The front door speaker (LH) should sound.

STEP 21. Check front door speaker (LH) connector E-10 and radio and audio amplifier connector D-20 for damage.

Q: Are harness connectors E-10 and D-20 in good condition?

YES : Go to Step 22 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The door speaker (LH) should sound.







STEP 22. Check the harness wires between front door speaker (LH) connector E-10 and amplifier connector D-20.
NOTE: After inspecting intermediate connectors C-91, inspect the wire. If intermediate connectors C-91 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between door speaker (LH) connector E-10 and amplifier connector D-20 in good condition?

YES : Go to Step 23 .

NO : Repair them. The door speaker (LH) should sound.



STEP 23. Check the DIN cable between amplifier and radio and CD player.

Q: Is the DIN cable between amplifier and radio and CD player in good condition?

YES : Repair or replace the amplifier or radio and CD player. The front door speaker (LH) should sound.

NO : Repair or replace it. The front door speaker (LH) should sound.

STEP 24. Check the front door speaker (RH).


(1) Remove the front door speaker (RH).

(2) Check that the front door speaker (RH) generates noise when a five-volt voltage is applied on the front door speaker (RH) terminal.

Q: Is the front door speaker (RH) generating noise?

YES : Go to Step 25 .

NO : Replace the front door speaker (RH). The front door speaker (RH) should sound.






STEP 25. Check front door speaker (RH) connector E-01 and amplifier connector D-20 for damage.

Q: Are harness connectors D-20 and E-01 in good condition?

YES : Go to Step 26 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The front door speaker (RH) should sound.







STEP 26. Check the harness wires between front door speaker (RH) connector E-01 and amplifier connector D-20.
NOTE: After inspecting intermediate connectors C-95, inspect the wire. If intermediate connectors C-95 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between front door speaker (RH) connector E-01 and amplifier connector D-20 in good condition?

YES : Go to Step 27 .

NO : Repair them. The front door speaker (RH) should sound.



STEP 27. Check the DIN cable between amplifier and radio and CD player.

Q: Is the DIN cable in good condition?

YES : Repair or replace the amplifier or radio and CD player. The front door speaker (RH) should sound.

NO : Repair or replace it. The front door speaker (RH) should sound.

STEP 28. Check the rear speaker (LH).


(1) Remove the rear speaker (LH).

(2) Check that the rear speaker (LH) generates noise when a five-volt voltage is applied on the rear speaker (LH) terminal.

Q: Is the rear speaker (LH) generating noise?

YES : Go to Step 29 .

NO : Replace the rear speaker (LH). The rear speaker (LH) should sound.






STEP 29 Check rear speaker (LH) connector F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and amplifier connector D-20 for damage.

Q: Are harness connectors F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and D-20 in good condition?

YES : Go to Step 30 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The rear speaker (LH) should sound.







STEP 30. Check the harness wires between rear speaker (LH) connector F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and amplifier connector D-20.

NOTE: After inspecting intermediate connectors C-90, inspect the wire. If intermediate connectors C-90 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between rear door speaker (LH) connector F-23 <ECLIPSE> or D-22 <ECLIPSE SPYDER> and amplifier connector D-20 in good condition?

YES : Go to Step 31 .

NO : Repair them. The rear speaker (LH) should sound.



STEP 31. Check the DIN cable between amplifier and radio and CD player.

Q: Is the DIN cable in good condition?

YES : Repair or replace the amplifier or radio and CD player. The rear speaker (LH) should sound.

NO : Repair or replace it. The rear speaker (LH) should sound.

STEP 32. Check the rear speaker (RH).


(1) Remove the rear speaker (RH).

(2) Check that the rear speaker (RH) generates noise when a five-volt voltage is applied on the rear speaker (RH) terminal.

Q: Is the rear speaker (RH) generating noise?

YES : Go to Step 33 .

NO : Replace the rear speaker (RH). The rear speaker (RH) should sound.






STEP 33. Check rear speaker (RH) connector F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and amplifier connector D-20 for damage.

Q: Are harness connectors D-20 and F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> in good condition?

YES : Go to Step 34 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The rear speaker (RH) should sound.







STEP 34. Check the harness wire between rear speaker (RH) connector F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and audio amplifier connector D-20.

NOTE: After inspecting intermediate connectors C-90, inspect the wire. If intermediate connectors C-90 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Is the harness wire between rear speaker (RH) connector F-19 <ECLIPSE> or D-21 <ECLIPSE SPYDER> and amplifier connector D-20 in good condition?

YES : Go to Step 35 .

NO : Repair it. The rear speaker (RH) should sound.



STEP 35. Check the DIN cable between amplifier and radio and CD player.

Q: Is the DIN cable in good condition?

YES : Repair or replace the amplifier or radio and CD player. The rear door speaker (RH) should sound.

NO : Repair or replace it. The rear door speaker (RH) should sound.

STEP 36. Check the woofer.


(1) Remove the woofer.

(2) Check that the woofer generates noise when a five-volt voltage is applied on the woofer terminal.

Q: Is the woofer generating noise?

YES : Go to Step 37 .

NO : Replace the woofer. The woofer should sound.









STEP 37. Check woofer connector C-08 and amplifier connector D-20 for damage.

Q: Are harness connectors C-08 and D-20 in good condition?

YES : Go to Step 38 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The woofer should sound.





STEP 38. Check the harness wires between woofer connector C-08 and amplifier connector D-20.

Q: Are the harness wires between woofer connector C-08 and amplifier connector D-20 in good condition?

YES : Go to Step 39 .


NO : Repair them. The woofer should sound.

STEP 39. Check the DIN cable between amplifier and radio, tape player and CD auto changer.

Q: Is the DIN cable in good condition?

YES : Repair or replace the amplifier or radio and CD player. The woofer should sound.

NO : Repair or replace it. The woofer should sound.




STEP 40. Check the tweeter (LH).

- (1) Remove the tweeter (LH).
- (2) Check that the tweeter (LH) generates noise when a five-volt voltage is applied on the tweeter (LH) terminal.

Q: Is the tweeter (LH) generating noise?

YES : Go to Step 41 .

NO : Replace the tweeter (LH). The tweeter (LH) should sound.









STEP 41. Check tweeter (LH) connector E-08 and amplifier connector D-20 for damage.

Q: Are harness connectors D-20 and E-08 in good condition?

YES : Go to Step 42 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The tweeter (LH) should sound.





STEP 42. Check the harness wires between tweeter (LH) connector E-08 and amplifier connector D-20.

NOTE: After inspecting intermediate connectors C-91, inspect the wire. If intermediate connectors C-91 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between tweeter (LH) connector E-08 and amplifier connector D-20 in good condition?

YES : Go to Step 43 .


NO : Repair them. The tweeter (LH) should sound.

STEP 43. Check the DIN cable between amplifier and radio and CD player.

Q: Is the DIN cable in good condition?

YES : Repair or replace the amplifier or radio and CD player. The tweeter (LH) should sound.

NO : Repair or replace it. The tweeter (LH) should sound.




STEP 44. Check the tweeter (RH).

- (1) Remove the tweeter (RH).
- (2) Check that the tweeter (RH) generates noise when a five-volt voltage is applied on the tweeter (RH) terminal.

Q: Is the tweeter (RH) generating noise?

YES : Go to Step 45 .

NO : Replace the tweeter (RH). The tweeter (RH) should sound.









STEP 45. Check tweeter (RH) connector E-03 and amplifier connector D-20 for damage.

Q: Are harness connectors D-20 and E-03 in good condition?

YES : Go to Step 46 .

NO : Repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The tweeter (RH) should sound.





STEP 46. Check the harness wires between tweeter (RH) connector E-03 and amplifier connector D-20.

NOTE: After inspecting intermediate connectors C-95, inspect the wire. If intermediate connectors C-95 is damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between tweeter (RH) connector E-03 and amplifier connector D-20 in good condition?

YES : Go to Step 47 .

NO : Repair them. The tweeter (RH) should sound.

STEP 47. Check the DIN cable between amplifier and radio, tape player and CD auto changer.

Q: Is the DIN cable in good condition?

YES : Repair or replace the amplifier or radio and CD player. The tweeter (RH) should sound.

INSPECTION PROCEDURE 4: Separate type CD player or CD auto changer does not operate.

TECHNICAL DESCRIPTION (COMMENT)

The separate type CD player or CD auto changer is connected via only the DIN cable to the radio, tape player and CD player. Therefore, if the DIN cable is defective, the audio system does not operate normally.

TROUBLESHOOTING HINTS

- Damaged DIN cable.
- Malfunction of the separate type CD player or CD auto changer.
- Malfunction of the radio, tape player and CD player.


DIAGNOSIS

If the DIN cable between separate type CD player or CD auto changer and radio, tape player and CD player is damaged, repair or replace it. The separate type CD player or CD auto changer should operate normally.


If the DIN cable is in good condition, repair or replace the separate type CD player or CD auto changer or radio, tape player and CD player. The separate type CD player or CD auto changer should operate normally.

INSPECTION PROCEDURE 5: The multi-center display does not display the information concerning the audio system correctly.

Multi-center Display Communication Circuit



TSB Revision

**CIRCUIT OPERATION**

The multi-center display and the radio, tape player, CD player and CD auto changer communicate with each other. The multi-center display shows the information concerning the radio, tape player, CD player and CD auto changer on the screen, based on that communication.

TECHNICAL DESCRIPTION (COMMENT)

The cause is probably a faulty multi-center display communication circuit.

TROUBLESHOOTING HINTS

- Damaged harness wire or connector.
- Malfunction of the multi-center display.
- Malfunction of the radio, tape player, CD player and CD auto changer.

DIAGNOSIS**Required Special Tool:**

- MB991223: Harness set

STEP 1. Check the time display function of the multi-center display.

Q: Does the time display function of the multi-center display operate normally?

YES : Go to Step 2 .


NO : Refer to multi-center display.


STEP 2. Check multi-center display connector C-09 and radio, tape player, CD player and CD auto changer connector C-21 for damage.

Q: Are multi-center display connector C-09 and radio, tape player, CD player and CD auto changer connector C-21 in good condition?

YES : Go to Step 3 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.54B-9](#). The multi-center display should display the information concerning the audio system correctly.






STEP 3. Check the harness wires between multi-center display connector C-09 and radio, tape player, CD player and CD auto changer connector C-21.

Q: Are the harness wires between multi-center display connector C-09 and radio, tape player, CD player and CD auto changer connector C-21 in good condition?





YES : Repair or replace the multi-center display or radio, tape player, CD player and CD auto changer.

NO : Repair them. The multi-center display should display the information concerning the audio system correctly.

INSPECTION PROCEDURE 6: Sound volume is not changed if the vehicle speed is changed.
<vehicles with amplifier>



W1S12M00AA
AC004899AB



CIRCUIT OPERATION

If the vehicle speed signal is transmitted to the radio and CD player, sound volume will be changed.

TECHNICAL DESCRIPTION (COMMENT)

If the radio and CD player normally, the cause is probably a faulty radio and CD player to vehicle speed sensor circuit.

NOTE: The vehicle speed signal is shared by the MFI system, automatic transaxle, combination meter. If a problem is not resolved, observe the troubleshooting. (Refer to GROUP 13A, Diagnosis P.13A-22, refer to GOUP 23A, Automatic Transaxle Diagnosis P.23A-46.

TROUBLESHOOTING HINTS

- Damaged harness wire or connector.
- Malfunction of the vehicle speed sensor.
- Malfunction of the multi-center display.
- Malfunction of the radio, tape player, CD player or CD auto changer.

DIAGNOSIS

Required Special Tools:

- MB991223: Harness set

STEP 1. Check the combination meter.

Q: Does the combination meter (speedometer) operate normally?

YES : Go to Step 2 .

NO : Refer to [P.54A-30](#).

STEP 2. Check the multi-center display.

Q: Does the multi-center display operate normally?

YES : Go to Step 3 .




NO : Refer to [P.54A-190](#).

STEP 3. Check the multi-center display connector C-09 and vehicle speed sensor connector B-39 for damage.

Q: Are multi-center display connector C-09 and vehicle speed sensor connector B-39 in good condition?

YES : Go to Step 4 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The sound volume should depend on vehicle speed.







STEP 4. Check the harness wires between multi-center display connector C-09 and vehicle speed sensor connector B-39.

NOTE: After inspecting intermediate connector B-36<MIT> and C-28 and joint connector C-77 inspect the wires. If intermediate connector B-36<MIT> and C-28 and joint connector C-77 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Are the harness wires between multi-center display connector C-09 and vehicle speed sensor connector B-39 in good condition?

YES : Repair or replace the radio and CD player. The sound volume should depend on vehicle speed.

NO : Repair them. The sound volume should depend on vehicle speed.



INSPECTION PROCEDURE 7: Noise appears at certain places when traveling (AM).

DIAGNOSIS

STEP 1. Check the noise occur when entering or near a particular structure (building, tunnel, mountain, etc)**Q: STEP 1. Does the noise occur when entering or near a particular structure (building, tunnel, mountain, etc.)?****YES :** Go to Step 3 .**NO :** Go to Step 2 .

STEP 2. After taking the following measures to prevent the noise, check that no noise appears.

- (1) Change to a different station with a stronger wave to boost resistance to interference.
- (2) Suppress high tones to reduce noise.
- (3) Extend antenna completely.

Q: Do the following measures eliminate the noise?**YES :** The following causes can be considered.**NO :** Go to Step 4.


STEP 3. Ask the owner about the state of the noise.

- (1) Find out the following information from the owner.
- (2) Place where the noise occurs.
- (3) Locality conditions (valley, mountain, etc.)
- (4) Name and frequency of stations affected by noise

Q: Which is the noise, vehicle noise or external noise?**Vehicle noise :** It may not be possible to prevent noise if the signal is weak.**External noise :** In almost all cases, prevention on the receiver side is impossible. Weak signals especially are susceptible to interference. Go to Step 4 .

STEP 4. Check that there is no noise.**Q: Does noise still exist?****YES :** If there is more noise than on radios in other vehicles, find out the noise condition and the name and frequency of the receiving stations from the owner, and consult with the radio manufacturer's service center.**NO :** Normal.

INSPECTION PROCEDURE 8: Noise appears at certain places when traveling (FM).



DIAGNOSIS

NOTE: About FM waves: FM waves have the same properties as light, and can be deflected and blocked. Wave reception is not possible in the shadow of obstructions such as buildings or mountains.

1. The signal becomes weak as the distance from the station's transmission antenna increases. This may depend on the signal strength of the transmitting station and intervening geographical formation of buildings. Generally speaking, the area of good reception is approximately 20 - 25 km (12 - 16 miles) for stereo reception, and 30 - 40 km (19 - 25 miles) for monaural reception.
2. The signal becomes weak when an area of shadow from the transmitting antenna (places where there are obstructions such as mountains or buildings between the station transmitter and the vehicle), and noise will appear. <This is called first fading, and gives a steady buzzing noise.>
3. If a direct signal hits the antenna at the same time as a signal reflected by obstructions such as mountains or buildings, interference of the two signals will generate noise. During traveling, noise will appear each time the vehicle's antenna passes through this kind of obstructed area. The strength and interval of the noise varies according to the signal strength and the conditions of deflection. <This is called multipath noise, and is a repetitive buzzing.>
4. Since FM stereo transmission and reception has a weaker field than monaural, it is often accompanied by a hissing noise.

After taking measures to prevent the noise, check that no noise occurs.

5. Change to a different station with a stronger wave to boost resistance to interference.
6. Suppress high tones to reduce noise.
7. Extend antenna completely.

If there is noise, the following causes can be considered.

8. If due to vehicle noise: It may not be possible to prevent noise if the signal is weak.
9. If due to external noise: In almost all cases, prevention on the receiver side is impossible. Weak signals especially are susceptible to interference.

If there is more noise than on radios in other vehicles, find out the noise condition and the name and frequency of the receiving stations from the owner, and consult with the radio manufacturer's service center.

INSPECTION PROCEDURE 9: Mixed with noise, only at night (AM).

The following factors can be considered as possible causes of noise appearing at night.

1. Factors due to signal conditions: Due to the fact that long-distance signals are more easily received at night, even stations that are received without problem during the day may experience interference in a general worsening of reception conditions. The weaker a station is the more susceptible it is to interference, and a change to different station or the appearance of a beating sound* may occur.

NOTE: Beat sound: Two signals close in frequency interfere with each other, creating a repetitious high-pitched sound. This sound is generated not only by sound signals but electrical waves as well.*

2. Factors due to vehicles noise: Generator noise may be a cause.

DIAGNOSIS

STEP 1. Check that the noise still obvious even when the lights are off.

Q: Is the noise still obvious even when the lights are off?

YES : Go to Step 2 .

NO : Go to Step 3 .

STEP 2. Check hat the following actions.

- (1) Tune to a station with a stronger wave.
- (2) Tune to a station with a stronger wave without completely extending the antenna (Whip antenna).

Q: Is there more noise than on radio in other vehicles?

YES : Consult the radio manufacturer's service center.

NO : Check that there is no noise.

STEP 3. Check that the noise fades away when the vehicle harness is moved away from the radio (if the harness is not in the proper position).

Q: Does the noise fade away when the vehicle harness is moved any from the radio (If the harness is not in the proper position)?

NO : If there is more noise than other radios, consult the radio manufacturer's service center.

INSPECTION PROCEDURE 10: Broadcasts can be heard but both AM and FM have a lot of noise.

DIAGNOSIS

STEP 1. Check that the noise occur when the engine is stopped or the engine is running.

Q: Does noise occur when the engine is stopped or the engine is running?

When the engine is stopped : Go to Step 2 .

When the engine is running : Check the vehicle's noise suppressor. (Refer to Inspection Procedure 12 P.54A-150.)

STEP 2. Check that the following actions disappear the noise.

- (1) Tune to a station with a stronger wave.
- (2) Extend the antenna completely (Mast antenna).
- (3) Adjust the sound quality to suppress high tones.

Q: Is the noise eliminated?

YES : Consult the radio manufacturer's service center.

NO : Go to Step 3 .

STEP 3. Check that the radio is correctly grounded

Q: Is the radio correctly grounded?

YES : Go to Step 4 .

NO : Consult the radio manufacturer's service center.

STEP 4. Check that the antenna plug properly connected to the radio?

Q: Is the antenna plug properly connected to the radio?

YES : Go to Step 7 .

NO : Go to Step 5 .

STEP 5. Check that the noise is eliminated when the antenna plug is properly attached.

Q: Is the noise eliminated?

YES : Consult the radio manufacturer's service center.

NO : Go to Step 6 .

STEP 6. Check that the antenna is in good condition and is it properly mounted.

Q: Is the antenna in good condition and is it properly mounted?

YES : Consult the radio manufacturer's service center.

NO : Go to Step 7 .

STEP 7. Clean the antenna plug and ground wire mounting area. Mount the antenna securely.

NOTE: Noise encountered during FM reception only due to differences in FM and AM system, FM is not as susceptible as AM to interference from engines, power lines, lighting, etc. On the other hand, due to the characteristics of FM waves, there are sometimes cases of noise or distortion which are generated by typical noise interference (first fading and multipath). (Refer to Inspection Procedure 8.) <Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>

NOTE: Furthermore, the amount of interference will be comparatively less for vehicles equipped with a diversity antenna system. If there is an equivalent amount of distortion in vehicles or radios of the same type, then differences will be because of differences in antenna systems, and this should be explained to the user.*

NOTE: Diversity antenna system: A system where two types of antenna (glass main antenna and glass sub antenna) are equipped and the antenna that provides the best reception can be selected.*

Q: Is the antenna in good condition?

YES : Consult the radio manufacturer's service center.

NO : Clean or repair it. Check the noise is eliminated. If the noise is not eliminated, consult the radio manufacturer's service center.

INSPECTION PROCEDURE 11: There is More Noise on either AM or FM.

DIAGNOSIS

There is much noise only on AM. Due to differences in AM and FM systems, AM is more susceptible to noise interference.

STEP 1. Check that there is noise under the following state(s).

- A motorcycle was passing.
- Lighting was flashing.
- A vehicle passed close by, but it appeared to be a vehicle generating a particularly large amount of noise radiation.
- Passed beneath a power line.
- Passed beneath a telephone line.
- Passed close by a signal generator.
- Passed close by some other sources of electrical noise.
- Passed under a bridge.

Q: Is there noise in the above states?

YES : Go to Step 3 .

NO : Go to Step 2 .

STEP 2. Continue to check for static; when static is detected, check for the conditions listed above.

Q: Is there noise in the state described in Step 1?

YES : Noise prevention on the radio side is difficult. If the problem is particularly worse than other radios, consult a service center.

NO : Go to Step 3 .

STEP 3. Check noise prevention on the radio side is difficult.

Q: Is the noise level worse than other radios?

YES : Consult a service center.Noise encountered during FM reception only. Due to differences in FM and AM systems, FM is not as susceptible as AM to interference from engines, power lines, lighting, etc. On the other hand, due to the characteristics of FM waves, there are sometimes cases of noise or distortion which are generated by typical noise interference (first fading and multipath). (Refer to Inspection Procedure 8.) <Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to Furthermore, the amount of interference will be comparatively less for vehicles equipped with a diversity antenna system*. If there is an equivalent amount of distortion in vehicles or radios of the same type, then differences will be because of differences in antenna systems, and this should be explained to the user. a problem with the radio.> Furthermore, the amount of interference will be comparatively less for vehicles equipped with a diversity antenna system*. If there is an equivalent amount of distortion in vehicles or radios of the same type, then differences will be because of differences in antenna systems, and this should be explained to the user.

NO : f the noise level is roughly the same as other radios, there is no action to be taken.

INSPECTION PROCEDURE 12: There is noise when starting the engine.**DIAGNOSIS****⚠ CAUTION**




- Connecting a high tension cable to the noise filter may destroy the noise filter and should never be done.
- Check that there is no external noise. Since failure to do this may result in an incorrect diagnosis due to the inability to identify the noise source, this operation must be performed.
- Noise prevention should be performed by suppressing strong sources of noise step by step.

NOTE: Capacitor: The capacitor does not pass DC current, but as the number of waves increases when it passes AC current, impedance (resistance against AC) decreases, and current flow is facilitated. A noise suppressing capacitor which take advantage of this property is inserted between the power line for the noise source and the ground. This suppresses noise by grounding the noise component (AC or pulse signal) to the body of the vehicle.

NOTE: Coil: The coil passes DC current, but impedance rises as the number of waves increases relative to the AC current. A noise suppressing coil which takes advantage of this property is inserted into the power line for the noise source, and works by preventing the noise component from flowing or radiating out of the line.

NOISE TYPE SOUNDS ARE IN PARENTHESES	CONDITIONS	CAUSE	REMEDY
AM, FM: ignition noise (popping, snapping, cracking, buzzing)	<ul style="list-style-type: none"> • Increasing the engine speed causes the generator whine sound to speed up and the volume to decrease • Disappears when the ignition switch turned to 	<ul style="list-style-type: none"> • Mainly due to the spark plugs • Due to engine noise 	<ul style="list-style-type: none"> • Check or replace the ground cable. • Check or replace the noise capacitor. <2.4L ENGINE>

NOISE TYPE SOUNDS ARE IN PARENTHESES	CONDITIONS	CAUSE	REMEDY
Other electrical components	-	Noise may occur as the electrical components become older.	Repair or replace the electrical components.
Static electricity (cracking, crinkling)	<ul style="list-style-type: none"> Disappears when the vehicle is completely stopped. Severe when the clutch is engaged 	Occurs when parts or wiring move for some reason and contact metal parts of the body.	Return parts or wiring to their proper position.
Static electricity (cracking, crinkling)	<ul style="list-style-type: none"> Various noise are produced depending on the body part of the vehicle. 	Due to removal of the front hood, bumpers, exhaust pipe and muffler, suspension, etc.	Ground parts by bonding. Cases where the problem is not eliminated by a signal response to one area are common, due to several body parts being imperfectly grounded.



AC004023 AB

INSPECTION PROCEDURE 13: Some noise appears when there is vibration or shocks during traveling.

DIAGNOSIS

STEP 1. Check that the connectors are properly connected.

NOTE: For the corresponding connectors, etc., refer to GROUP 90, Audio System <vehicles without amplifier P.00E-2> or <vehicles with amplifier P.00E-2.>

Q: Are the connectors properly connected?

YES : Go to Step 2 .

NO : Check the condition of the connector. Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Check that there is no noise.

STEP 2. Check that noise appear when the radio switch is turned on while the vehicle is stopped and the radio is tapped while tuned away from a station

NOTE: Static electricity noise: Body static electric from the shock absorber rubber bushings used to prevent vibration, tires, etc. occurs because of separation from the ground, causing a buzzing noise. Since no measures can be taken to discharge the static electricity of the vehicle body. Check that there is no noise.

Q: Does noise appear when the radio switch is turned on while the vehicle is stopped and the radio is tapped while tuned away from a station?

YES : Go to Step 3 .

NO : It may be static electricity noise.

STEP 3. Check that the radio correctly grounded.

Q: Is the radio correctly grounded?

YES : Go to Step 4 .

NO : Tighten the screw securely. Check that there is no noise.

STEP 4. Check that the antenna is correctly grounded. (If noise appears when the antenna is moved, this means the ground is not securely connected.)

Q: Is the antenna correctly grounded?

YES : Repair or replace the radio. Check that there is no noise.

NO : If rust is present on the antenna ground screw, clean off the rust and tighten the ground screw securely. Check that there is no noise.

INSPECTION PROCEDURE 14: Noise Sometimes Appears on FM During Traveling.

DIAGNOSIS

Refer to GROUP 90, Audio System <vehicles without amplifier P.00E-2> or <vehicles with amplifier P.00E-2.>

DIAGNOSIS

STEP 1. Retune the radio, and check that no noise appears.

Q: Does the problem clear up when returned?

YES : Check that there is no noise.

NO : Go to Step 2 .

STEP 2. Check that the noise appears only in certain locations and only with certain stations.

NOTE: Multipath noise and fading noise: Because of the frequency of FM waves in extremely high, it is highly susceptible to effects from geological formations and buildings. These effects disrupt the broadcast signal and obstruct reception in several ways.

- *Multipath noise*
This describes the echo that occurs when the broadcast signal is reflected by a large obstruction and enters the receiver with a slight time delay relative to the direct signal (repetitious buzzing).
- *Fading noise*
This is a buzzing noise that occurs when the broadcast beam is disrupted by obstructing objects and the signal strength fluctuates intricately within a narrow range.

Q: Does the problem appear only in certain locations and only with certain stations?

YES : The effect of an electrical field condition (multipath noise, fading noise) could be the cause. Check that there is not noise.

NO : Go to Step 3 .

STEP 3. Check that the connectors are properly connected.

NOTE: For the corresponding connectors, etc., refer to Audio System <vehicles without amplifier P.00E-2> or <vehicles with amplifier P.54A-92.>

Q: Are the connectors properly connected?

YES : Go to Step 4 .

NO : Check the condition of the connector. Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Check that there is no noise.

STEP 4. Check that noise appears when the radio switch is turned on while the vehicle is stopped.

NOTE: Static electricity noise: Body static electric from the shock absorber rubber bushings used to prevent vibration, tires, etc. occurs because of separation from the ground, causing a buzzing noise. There is no measures to discharge the static electricity of the vehicle body. Check that there is no noise.

Q: Does noise appear when the radio switch is turned on while the vehicle is stopped and the radio is tapped while tuned away from a station?

YES : Go to Step 5 .

NO : It may be static electricity noise.

STEP 5. Check that the radio is correctly grounded.

Q: Is the radio correctly grounded?

YES : Go to Step 6 .

NO : Tighten the screw securely. Check that there is no noise.

STEP 6. Check that the antenna is correctly grounded. (If noise appears when the antenna is moved, this means the ground is not securely connected.)

Q: Is the antenna correctly grounded?

YES : Repair or replace the radio. Check that there is no noise.

NO : If rust is present on the antenna ground screw, clean off the rust and tighten the ground screw securely. Check that there is no noise.

INSPECTION PROCEDURE 15: Ever-present Noise.**DIAGNOSIS**

Noise is often created by the following factors, and often the radio is OK when it is checked individually.

- Traveling conditions of the vehicle
- Terrain of area traveled through
- Surrounding buildings
- Signal conditions
- Time period

For this reason, if there are still problems with noise even after the measures described in inspection procedure 7 to 14 have been taken, get information on the factors listed above as well as determining whether the problem occurs with AM or FM, the station names, frequencies, etc. and contact the radio manufacturer's service center.

INSPECTION PROCEDURE 16: There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.**DIAGNOSIS**

STEP 1. Make sure that the check is being conducted under special electrical field conditions.

Example: In an underground garage or inside a building.

Q: Is the check being conducted under special electrical field conditions?

YES : Go to Step 2 .

NO : Go to Step 3 .

STEP 2. Check that proper performance is obtained when the vehicles is moved.

Q: Is proper performance obtained when the vehicle is moved?

YES : The radio should sound normally.

NO : Go to Step 3 .

STEP 3. Check that tuning solve the problem.

Q: Does tuning solve the problem?

YES : The radio should sound normally.

NO : Go to Step 4 .

STEP 4. Check the antenna plug and radio unit connected

Q: Are the antenna plug and radio unit properly connected?

YES : Go to Step 5 .

NO : Reconnect the antenna plug and radio unit properly. the radio should sound normally.

STEP 5. Check that the problem disappear if another radio is used.

Q: Does the problem disappear if another radio is used?

YES : Repair or replace the radio. The radio should sound normally.

INSPECTION PROCEDURE 17: Poor reception.**DIAGNOSIS**

STEP 1. Make sure that the check being conducted under special electrical field conditions.

Q: Is the check being conducted under special electrical field conditions (such as in an underground garage or inside a building)?

YES : Go to Step 2 .

NO : Go to Step 3 .

STEP 2. Check that proper performance is obtained when the vehicle is moved.

Q: Is proper performance obtained when the vehicle is moved?

YES : Check that a poor reception is resolved.

NO : Go to Step 3 .

STEP 3. Check that tuning solves the problem.

Q: Does tuning solve the problem?

YES : Check that a poor reception is resolved.

NO : Go to Step 4 .

STEP 4. Check that the problem is limited to the reception of a specific radio station from a specific position.

NOTE: Multipath noise and fading noise: Because the frequency of FM waves is extremely high, it is highly susceptible to effects from geological formations and buildings. These effects disrupt the broadcast signal and obstruct reception in several ways.

- *Multipath noise*

This describes the echo that occurs when the broadcast signal is reflected by a large obstruction and enters the receiver with a slight time delay relative to the direct signal (repetitious buzzing).

- *Fading noise*

This is a buzzing noise that occurs when the broadcast beam is disrupted by obstructing objects and the signal strength fluctuates intricately within a narrow range.

Q: Is the problem limited to the reception of a specific radio station from a specific position?

YES : Go to Step 5 .

NO : Check that a poor reception is resolved.

STEP 5. Check that the antenna plug is connected to the radio properly.

Q: Is the antenna plug connected to the radio properly?

YES : Go to Step 6 .

NO : Reconnect the antenna plug and radio unit properly. Check that a poor reception is resolved.

STEP 6. Check that the problem disappear when another radio is used?

Q: Does the problem disappear if another radio is used?

YES : Repair or replace the radio. Check that a poor reception is resolved.

INSPECTION PROCEDURE 18: Distortion on AM or on both AM and FM.

DIAGNOSIS

STEP 1. Check how much distortion there is.

Q: How much distortion is there?

Occasional distortion : Go to Step 2 .

Constant distortion : Go to Step 3 .

STEP 2. Check that there is distortion near the radio station.

Q: Is there distortion near the radio station?

YES : The antenna may receive too strong signal.

NO : Go to Step 3 .

STEP 3. Check that the speaker cords are in contact with the cone paper.

- Q: Are the speaker cords in contact with the cone paper?**
YES : Move the cords away from the cone paper. Check that a distortion is resolved.
NO : Go to Step 4 .

STEP 4. Remove the speakers, and check for torn cone paper or foreign material.

- Q: Is there torn cone paper or foreign material?**
YES : Repair or replace the speakers. Check that a distortion is resolved.
NO : Go to Step 5 .

STEP 5. Check for distortion with the speaker installed.

- Q: Does a distortion occur?**
YES : Install the speaker securely. Check that a distortion is resolved.
NO : Repair or replace the radio. Check that a distortion is resolved.

INSPECTION PROCEDURE 19: Distortion on FM only.

DIAGNOSIS

STEP 1. Check that the distortion persist when the radio is turned to another station.

- Q: Does the distortion persist when the radio is turned to another station?**
YES : Go to Step 2 .
NO : The signal from that station is too weak.

STEP 2. Check that the distortion increase or decrease when the vehicle is moved.

- Q: Does distortion increase or decrease when the vehicle is moved?**
YES : The cause may be multipath noise.
NO : Repair or replace the radio. Check that a distortion is resolved.

INSPECTION PROCEDURE 20: Using the auto select function, too few automatic stations are selected.

DIAGNOSIS

STEP 1. Consider the number of radio stations. Check that there are enough radio stations in the area.

- Q: Consider the number of radio stations. Are there enough in the area?**
YES : Go to Step 2 .
NO : Confirm automatic selection selects the strongest signals in the area. If not, go to Step 3 .

STEP 2. Consider the distance to the radio stations. Check that the transmitting antennas are within 2 miles.

- Q: Consider the distance to the radio stations. Are the transmitting antennas within 2 miles?**
YES : Go to Step 3 .
NO : Confirm automatic selection selects the strongest signals in the area. If not, go to Step 4 .

STEP 3. Make sure that the check is being conducted under special electrical field conditions.

- Q: Is the check being conducted under special electrical field conditions (such as in an underground garage or inside a building)?**
YES : Go to Step 4 .
NO : Go to Step 5 .

STEP 4. Check that the proper performance is obtained when the vehicle is moved.

Q: Is proper performance obtained when the vehicle is moved?

YES : The auto-select function should operate normally.

NO : Go to Step 5 .

STEP 5. Check that the antenna plug is connected to the radio properly.

Q: Is the antenna plug connected to the radio properly?

YES : Go to Step 6 .

NO : The antenna plug is reconnected to the radio properly. The auto-select function should operate normally.


STEP 6. Check that the problem disappears when another radio is used.

Q: Does the problem disappear if another radio is used?




YES : Repair or replace the radio. The auto-select function should operate normally.

INSPECTION PROCEDURE 21: Preset station are erased.

Memory Backup Power Supply Circuit



AC004393
WOS14M02A



CIRCUIT OPERATION

The power is constantly supplied to the radio, tape player, CD player and CD auto changer.

TECHNICAL DESCRIPTION (COMMENT)

The cause is probably a faulty radio, tape player, CD player and CD auto changer memory backup power supply circuit system.

TROUBLESHOOTING HINTS

- Damaged harness wire or connector.
- Malfunction of the radio, tape player, CD player and CD auto changer.

DIAGNOSIS

Required Special Tool:

- MB991223: Harness set


STEP 1. Check the radio, tape player, CD player and CD auto changer memory backup power supply circuit by back probing.


- (1) Do not disconnect radio, tape player, CD player and CD auto changer connector C-22.
- (2) Measure the voltage between terminal number 11 and ground by backprobing.

Q: Is the voltage approximately 12 volts (battery positive voltage)?

YES : Repair or replace the radio, tape player, CD player and CD auto changer. Check that a memory is retained.

NO : Go to Step 2 .






STEP 2. Check harness connector C-22 at the radio, tape player, CD player and CD auto changer for damage.

Q: Is harness connector C-22 in good condition?

YES : Go to Step 3 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that a memory is retained.





STEP 3. Check the harness wires between radio, tape player, CD player and CD auto changer connector C-22 and battery.

NOTE: After inspecting intermediate connector C-89 and joint connector C-78 and junction block connector C-109 and C-102, inspect the wire. If intermediate connector C-89 and joint connector C-78 and junction block connector C-109 and C-102 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Are the harness wires between the connector C-22 and battery in good condition?

YES : Repair them. Check that a memory is retained.

NO : Repair or replace the radio, tape player, CD player and CD auto changer. Check that a memory is retained.



INSPECTION PROCEDURE 22: Cassette tape can not be inserted.

DIAGNOSIS

STEP 1. Check that there are any foreign objects inside the cassette player.

NOTE: Attempting to eliminate a foreign object (e.g., a coin or clip, etc.) in the cassette player may damage the mechanism. The player should be taken to a service dealer for repair.

Q: Are there any foreign objects inside the cassette player?

YES : There are any foreign objects inside the cassette player, remove the object(s). A cassette tape should be inserted normally.

NO : Go to Step 2.

STEP 2. Check that the cassette player works when another tape is inserted.

NOTE: Check that the tape label is not loose, that the tape case is not deformed and that the tape is tightly wound. Also, tape with a length of C-120 or greater can often get caught in the mechanism and should not be used.

Q: Does the cassette player work if another tape is inserted?

YES : The cassette tape used is defective. A cassette tape should be inserted normally.

NO : Repair or replace the cassette player. A cassette tape should be inserted normally.

INSPECTION PROCEDURE 23: Sound quality is poor, or sound is weak.

DIAGNOSIS

STEP 1. Check that the player works normally if the tape is changed.

NOTE: Check that the tape label is not loose, that the tape case is not deformed and that the tape is tightly wound. Also, tapes with a length of C-120 or greater can often get caught in the mechanism and should not be used.

Q: Does the player work normally if the tape is changed?

YES : The tape used is defective.

NO : Go to Step 2 .

STEP 2. check that the player play OK if the tape player head is cleaned.

Q: Does the player play OK if the tape player head is cleaned?

YES : The sound quality should return to normal.

NO : Go to step 3 .

STEP 3. Check that the proper operation is obtained when the tape player is replaced.

Q: Is proper operation obtained when the tape player is replaced?

YES : Repair or replace the tape player. The sound quality should return to normal.

NO : Repair or replace the speakers. The sound quality should return to normal.

INSPECTION PROCEDURE 24: Cassette tape can not be ejected.

DIAGNOSIS

The problems covered here are all the result of the use of a bad tape (deformed or not properly tightened) or of a malfunction of the cassette player itself. Malfunctions involving the tape becoming caught in the mechanism and ruining the case are also possible, and attempting to force the tape out of the player can cause damage to the mechanism. The player should be taken to a service dealer for repair.

INSPECTION PROCEDURE 25: Uneven revolution. tape speed is fast or slow.**DIAGNOSIS**

STEP 1. Check that the tape player work normally when the tape is changed.

NOTE: Check that the tape label is not loose, that the tape case is not deformed and that the tape is tightly wound. Also, tape with a length of C-120 or greater can often get caught in the mechanism and should not be used.

Q: Does the player work normally if the tape is changed?

YES : The tape used is defective. The cassette tape speed should be stable.

NO : Go to step 2 .

STEP 2. Check that there are any foreign objects inside the cassette player.

NOTE: Attempting to eliminate a foreign object (e.g., a coin or clip, etc.) out of the cassette player may damage the mechanism. The player should be taken to a service dealer for repair.

Q: Are there any foreign objects inside the cassette player?

YES : The cassette tape speed should be stable.


NO : Go to step 3 .

STEP 3. Check that the head or capstan roller is dirty.

Q: Is the head or capstan roller dirty?

YES : Clean the head or capstan roller. The cassette tape speed should be stable.

NO : Repair or replace the tape player. The cassette tape speed should be stable.

**INSPECTION PROCEDURE 26: Automatic search does not work.****DIAGNOSIS**

STEP 1. Check that the "APS" (automatic search) button be depressed properly.

NOTE: When the time between songs on a tape is less than three seconds, or when there is a three second period in the middle of a song in which the volume level is extremely low, the automatic search

function may not work properly.

Q: Can the "APS" (automatic search) button be depressed properly?

YES : Go to step 2 .

NO : The button is operated improperly. Replace or repair tape player. Check that the automatic search function operates normally.

STEP 2. Check that the player works when the tape is changed.

NOTE: Ensure that the tape label is not loose, that the tape itself is not deformed and that the tape is tightly wound. Also, tapes of C-120 or greater length often get caught in the mechanism and should not be used.

Q: Does the player work if the tape is changed?

YES : The tape used is defective.

NO : Repair or replace the tape player. Check that the automatic search function operates normally.

INSPECTION PROCEDURE INSPECTION PROCEDURE 27: Malfunction of the auto reverse.

DIAGNOSIS

STEP 1. Check that the tape player works normally when the tape is changed.

NOTE: Ensure that the tape label is not loose, that the tape itself is not deformed and that the tape is tightly wound. Also, tape of C-120 or greater length often get caught in the mechanism and should not be used.

Q: Does the tape player work normally if the tape is changed?

YES : The tape used is defective. The auto reverse function should operate normally.

NO : Go to Step 2 .

STEP 2. Check that the problem only occur while the vehicle is being driven.

Q: Does the problem only occur while the vehicle is being driven?

YES : Go to Step 3 .

NO : Repair or replace the tape player. The auto reverse function should operate normally.

STEP 3. Check that the tape player is properly installed to the vehicle.

Q: Is the tape player properly installed to the vehicle?

YES : Repair or replace the tape player. The auto reverse function should operate normally.

NO : Repair the installation condition. The auto reverse function should operate normally.

INSPECTION PROCEDURE 28: Tape gets caught in mechanism.

NOTE: When the tape is caught in the mechanism, the tape case may not eject. When this occurs, do not try to force the tape out as this may damage the tape player mechanism. Take the cassette to a service dealer for repair.

DIAGNOSIS

STEP 1. Check that the player works normally if tape is changed.

NOTE: Check that the tape label is not loose, that the tape itself is not deformed and that the tape is tightly wound. Also, tape with a length of C-120 or greater can often get caught in the mechanism and should not be used.

Q: Does the player work normally if tape is changed?

YES : The tape used is defective. The tape player should operate normally.

NO : Repair or replace the tape player. The tape player should operate normally.

INSPECTION PROCEDURE 29: CD can not be inserted.**DAIGNOSIS****STEP 1. Check that the shutter open when a CD is inserted.**

NOTE: If a CD is already loaded, does the shutter not open to allow insertion when another CD is inserted?

Q: Does the shutter open when a CD is inserted?

YES : Go to Step 2 .

NO : Take out the CD. Check that a CD can be inserted.

STEP 2. Check that the CD ejected from approximately 15 mm (0.6 inch) inside the insertion panel even though it can be inserted.

NOTE: If the key switch is not at "ACC" or "ON," the CD stops at depth of 15 mm below the panel surface even when it is inserted, and it will be rejected when pushed farther?

Q: Is the CD ejected from approximately 15 mm inside the insertion panel even though it can be inserted?

YES : Go to Step 3 .

NO : Check that a CD can be inserted.

STEP 3. Check that "E" (error) is displayed even though the CD is inserted completely.

NOTE: Even though the CD is loaded, "E" (error) is sometimes displayed with the CD rejected because of vibration/shock or dew on the CD face or optical lens.

Q: Though the CD is inserted completely, is "E" (error) displayed and the CD ejected?

YES : Go to Step 4 .

NO : Check that a CD can be inserted.

STEP 4A. Check the CD.

Q: Is the labeled side faced downward?

YES : Insert the CD correctly.

NO : Replace the CD. Check that a CD can be inserted.

STEP 4B. Check the CD.

Q: Is the recorded face of the CD dirty?

YES : Replace the CD. Check that a CD can be inserted.

STEP 4C. Check the CD.

Q: Is there dew on the recorded face of the CD?

YES : Remove the dew.

NO : Replace the CD. Check that a CD can be inserted.

INSPECTION PROCEDURE 30: No sound. (CD only)**DIAGNOSIS****STEP 1. Check that the CD play properly if another CD is inserted.**

Q: Does it play properly if another CD is inserted?

YES : The CD used is defective. The CD player should sound normally.

NO : Go to Step 2 .

STEP 2. Return it to the normal temperature, and recheck the operation. Check that the CD player operate properly.

Q: Return it to the normal temperature, and recheck the operation. Does it operate properly?

YES : The CD player should sound normally.

NO : Repair or replace the CD player. The CD player should sound normally.

INSPECTION PROCEDURE 31: CD sound skips.

DIAGNOSIS

STEP 1. Malfunction occurrence state.

Q: When does a malfunction occur?

While parking : Go to Step 2 .

While driving : Stop vehicle, go to Step 4 .

STEP 2. Check that the CD face is scratched or dirty.

Q: Is the CD face scratched or dirty?

YES : CD is defective, or clean the CD. Check that a CD sound skip is resolved.

NO : Go to Step 3 .

STEP 3. Check that the plays properly if another CD is inserted.

Q: Does it play properly if another CD is inserted?

YES : CD is defective. Check that a CD sound skip is resolved.

NO : Repair or replace the CD player. Check that a CD sound skip is resolved.

STEP 4. Check that sound skip when the side of the CD player is tapped.

NOTE: Check by using a proper CD which is free from scratches, dirt or any other abnormality.

Q: Does sound skip when the side of the CD player is tapped?

YES : Securely mount the CD player. Check that a CD sound skip is resolved.

NO : Check the sound skipping state in detail while driving, and then contact a service shop. Check that a CD sound skip is resolved.

INSPECTION PROCEDURE 32: Sound quality is poor.

DIANOSIS

Check that the play properly if another CD is inserted.

YES : CD used is defective. The sound quality should return to normal.

NO : Repair or replace the CD player. The sound quality should return to normal.

INSPECTION PROCEDURE 33: CD can not be ejected.

DIAGNOSIS

STEP 1. Check that the key switch (ignition key) at "ACC" or "ON".

Q: Is the key switch (ignition key) at "ACC" or "ON?"

YES : Go to Step 2 .

NO : Check the memory backup power supply circuit. Refer to Inspection Procedure 21 [P.54A-158](#).

STEP 2. Check that the combined amplifier or radio set connected securely.


Q: Is the combined amplifier or radio set connected securely?

YES : If the CD is not ejected, do not discard it, because the player may be damaged. Therefore, contact a service shop for repairs. Check that a CD can be ejected normally.






NO : Connect the connectors securely. Check that a CD can be ejected normally.

INSPECTION PROCEDURE 34: Motor Antenna Won't Extend or Retract.

Motor Antenna Circuit



AC004394
W1S14M04AA



CIRCUIT OPERATION

The motor antenna-ECU extends or retract the antenna when the radio switch is turned on or off with the ignition switch in the "ACC" or "ON" position.

TECHNICAL DESCRIPTION (COMMENT)

The cause is probably a defective motor antenna circuit system.

TROUBLESHOOTING HINTS

- Damaged harness wire or connector.
- Malfunction of the motor antenna.
- Malfunction of the motor antenna-ECU

DAIGNOSIS

STEP 1. Check the surface of the antenna pole.

Q: Isn't the surface of antenna pole dirty?

YES : Clean.

NO : Go to Step 2.

STEP 2. Check the motor antenna bent**Q: Is the antenna bent?**


- YES** : Repair the bent or replace the antenna pole.
NO : Go to Step 3.

STEP 3. Is the motor antenna assembly OK?

- (1) Disconnect motor antenna connector F-35.
- (2) Connect the circuit shown in the solid line.
- (3) Check that antenna extends when the circuit shown in the dotted line is connected.
- (4) Check that antenna retracts when the circuit shown in the dotted line is disconnected.

Q: Is motor antenna in good condition?


- YES** : Go to Step 4.
NO : Replace the motor antenna.

**STEP 4. Check the motor antenna assembly ground by backprobing**


- (1) Do not disconnect motor antenna assembly F-35 connector.
- (2) Measure the voltage between terminal number 5 and ground by backprobing.


Q: Is the resistance less than two ohm?

- YES** : Go to Step 7.
NO : Go to Step 5.

**STEP 5. Check motor antenna connector F-35 for damage.****Q: Are motor antenna connector F-35 in good condition?**

- YES** : Go to Step 6.
NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The motor antenna should work normally.






STEP 6. Check the harness wire between motor antenna connector F-35 and ground.

Q: Are the harness wires between motor antenna connector F-35 and ground in good condition?

YES : There is no action to be taken.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The motor antenna should work normally.




STEP 7. Check the motor antenna assembly power supply (ignition switch "ACC") by backprobing

- (1) Do not disconnect motor antenna assembly F-35 connector.
- (2) Turn the ignition switch "ACC."
- (3) Measure the voltage between terminal number 1 and ground by backprobing.

Q: Are the voltages approximately 12 volts (battery positive voltage)?

YES : Go to Step 10.

NO : Go to Step 8.







STEP 8. Check motor antenna connector F-35 for damage.

Q: Are motor antenna connector F-35 in good condition?

YES : Go to Step 9.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The motor antenna should work normally.



STEP 9. Check the harness wire between motor antenna connector F-35 and ignition switch (ACC).

NOTE: After inspecting intermediate connector C-89 and junction block connector C-101 and C-109, inspect the wire. If intermediate connector C-89 and junction block connector C-101 and C-109 are damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#).

Q: Are the harness wires between motor antenna connector F-35 and ignition switch (ACC) in good condition?

YES : There is no action to be taken.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The motor antenna should work normally.

STEP 10. Check the motor antenna assembly power supply circuit. [Ignition switch "ON (G1)"] by backprobing

(1) Do not disconnect motor antenna F-35 connector.

(2) Turn the ignition switch "ON."


(3) Measure the voltage between terminal number 6 and

ground by backprobing.

Q: Are the voltages proximately 12 volts (battery positive voltage)?

YES : Go to Step 13.

NO : Go to Step 11.







STEP 11. Check motor antenna connector F-35 for damage.

Q: Are motor antenna connector F-35 in good condition?

YES : Go to Step 12.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#). The motor antenna should work normally.






STEP 12. Check the harness wire between motor antenna connector F-35 and ignition switch (IG1).

NOTE: After junction block connector C-101 and C-113, inspect the wire. If junction block connector C-101 and C-113 are damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-23.

Q: Are the harness wires between motor antenna connector F-35 and ignition switch (IG1) in good condition?

YES : There is no action to be taken.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-9.



STEP 13. Check the motor antenna assembly power supply circuit. (battery) by backprobing

- (1) Do not disconnect motor antenna F-35 connector.
- (2) Measure the voltage between terminal number 8 and ground by backprobing.

Q: Are the voltages proximately 12 volts (battery positive voltage)?

YES : Replace the motor antenna assembly.


NO : Go to Step 14.





STEP 14. Check motor antenna connector F-35 for damage.

Q: Are motor antenna connector F-35 in good condition?

YES : Go to Step 15.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#).






STEP 15. Check the harness wire between motor antenna connector F-35 and battery.

NOTE: After inspecting joint connector C-78, intermediate connector C-89 and junction block connector C-109 and C-113, inspect the wire. If joint connector C-78, intermediate connector C-89 and junction block connector C-109 and C-113 are damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-23.

Q: Are the harness wires between motor antenna connector F-35 and battery in good condition?

YES : There is no action to be taken.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-9.



INSPECTION PROCEDURE 35: Motor Antenna Extends and Retracts but Does Not Receive Radio Signal.


DIAGNOSIS

STEP 1. Is the antenna normal?

Q: Is there continuity on the circuits from F to A, B, C, D and E, the circuit from G to H?

yes : Go to Step 2 .

NO : Repair or replace the antenna. Then check the malfunction is eliminated.



STEP 2. Check the motor antenna.





Q: Does the antenna operate normally when a new antenna assembly is directly install to the radio?

YES : Replace the motor antenna assembly.

NO : Radio and tape player may be defective. Carry out troubleshooting of the radio and tape player [P.54A-92](#).

SPECIAL TOOLS

M1544000600102

TOOL	TOOL NUMBER AND NAME	SUPERSESSSION	APPLICATION
<p>A</p>  <p>B</p>  <p>C</p>  <p>D</p>  <p>MB991223AC</p>	<p>MB991223</p> <p>A: MB991219</p> <p>B: MB991220</p> <p>C: MB991221</p> <p>D: MB991222</p> <p>Harness set</p> <p>A: Test harness</p> <p>B: LED harness</p> <p>C: LED harness adapter</p> <p>D: Probe</p>	<p>MB991223</p>	<p>Making voltage and resistance measurements during troubleshooting</p> <p>A: Connect pin contact pressure inspection</p> <p>B: Power circuit inspection</p> <p>C: Power circuit inspection</p> <p>D: Commercial tester connection</p>

ON-VEHICLE SERVICE

PROCEDURE FOR INPUT OF ANTI-THEFT CODE FOR ANTI-THEFT SYSTEM

M1544004400100

The radio, tape player, CD player and CD auto changer do not work under the following conditions:

Power supply to the radio, tape player, CD player and CD auto changer has been suspended for more than an hour continuously by removing the cable from the battery terminal or disconnecting the harness connectors.


The power supply to the radio, tape player, CD player and CD auto changer has been suspended for more than an hour due to a blown fuse or discharged battery.





If the radio, tape player, CD player and CD auto changer does not work for these conditions, enter the security code as follows:

The radio, tape player, CD player and CD auto changer has been replaced.

1. Confirm the security code using any of the following methods.

(1) Use the security code indicated on the cards retained in the vehicle.





- (2) If the security code is unknown owing to the owner's loss of the card:
 - a. Remove the radio, tape player, CD player and CD auto changer referring to P.54A-180.
 - b. Read the serial number stamped on the radio, tape player, CD player and CD auto changer.
 - c. Look up the security code (anti-theft code table) corresponding to the serial number.

- (3) When the radio, tape player, CD player and CD auto changer is replaced: Use the security code on the cards attached to the upper surface of the replacement radio, tape player, CD player and CD auto changer.

NOTE: Deliver the two cards to the owner.

2. Connect the radio to the vehicle harness.
3. Turn the ignition key to the "ACC" or "ON" position.
4. Press the "PWR" button, and "codE" will be displayed.

5. Press number 1 through number 4 memory select button to set the four-digit security code shown on the card. Every time each digit key is pressed, the figure changes as follows: 0 to 1 to 2 to 3 to 4 to 5 to 6 to 7 to 8 to 9 to 0
6. Press the "TAPE" button (type 1 and 3) or "CD" button (type 2), and a beep will be heard. If entered correctly, the radio and tape player will work.
7. If the security code is not accepted, "Err" is displayed. In a few seconds, it will change to "code." Then repeat steps 5 and 6.


NOTE:

- NOTE: The anti-theft system will allow three attempts maximum to input the correct code.
- NOTE: The second error is displayed as "2 Err." When the third error is made, "3 Err" is displayed and then the display changes to "OFF." If this should occur, the unit will not work any more.
- NOTE: To input the security code again, turn the ignition switch to the "ACC" or "ON" position and wait for one hour when "OFF" is displayed. After "OFF" disappears on the display, press the "PWR" button and "CODE" will be displayed. The security code can be input again.

Three-minute operation mode

To facilitate replacement or check, the radio and CD player can be operated for three minutes without inputting the security code.

1. Press the "PWR" button and "EJECT" button together to operate the radio and CD player.
2. In three minutes the unit will not be able to work. Then the radio and CD player will be switched off.


**SPEAKER TEST**

M1544005400073

Enter the speaker test mode according to the following steps:

1. Turn the Ignition switch to "ACC" or "ON" position and switch off the radio, tape player, CD player and CD auto changer.


TYPE 1



TYPE 2



TYPE 3



AC003980 AD

2. Press the following buttons in that order within sixty seconds from step (1).
 - (1) Memory select "1" button
 - (2) "TUNE/SEEK (DOWN)" button
 - (3) "TUNE/SEEK (UP)" button
 - (4) Memory select "6" button

3. Check that the speaker, which is displayed on the multi-center display, sounds (If the memory select "6" button is pressed, the speaker will be changed).
4. If a button other than the memory select "6" button and "EJECT" button (tape or CD) is pressed, or the ignition switch is turned to "LOCK" (OFF) position, you will exit from the speaker test mode.

DOOR SPEAKER (LH)
AND TWEETER (LH)



DOOR SPEAKER (RH)
AND TWEETER (RH)



REAR SPEAKER (LH)



REAR SPEAKER (RH)



NOTE

□ : OFF


■ : ILLUMINATES

▨ : FLASHES

ACX01941 AD

RADIO WITH TAPE PLAYER AND CD PLAYER
REMOVAL AND INSTALLATION

M1544001400093



AC003981 AB

RADIO RMEOVAL STEPS

1. CENTER PANEL ASSEMBLY (REFER TO GROUP 52A, INSTRUMENT PANEL P.52A-4.)
2. RADIO BRACKET
3. RADIO, TAPE CD PLAYER AND CD AUTO CHANGER

RADIO RMEOVAL STEPS (Continued)



4. CD PLAYER <VEHICLES WITH SEPARATE TYPE CD PLAYER>
5. DIN CABLE <VEHICLES WITH SEPARATE TYPE CD PLAYER>

SPEAKER

REMOVAL AND INSTALLATION

M1544002600119

CENTER SPEAKER <VEHICLES WITH CENTER SPEAKER>




NOTE
↔ : CLAW POSITION

AC001354 AB

REMOVAL STEPS

- MULTI-CENTER DISPLAY (REFER TO [P.54A-213.](#))
- 1. CENTER SPEAKER

TWEETER, DOOR SPEAKER



AC001355 AB

TWEETER REMOVAL STEPS <VEHICLES WITH TWEETER>

2. TWEETER COVER (REFER TO GROUP 51, DOOR MIRROR – DOOR MIRROR [P.51-26.](#))
3. TWEETER


DOOR SPEAKER REMOVAL STEPS

4. DOOR TRIM (REFER TO GROUP 42, DOOR – DOOR TRIM AND WATERPROOF FILM [P.42-71.](#))
5. DOOR SPEAKER BRACKET
6. DOOR SPEAKER

< ECLIPSE >

1.4 ± 0.1 N·m
12 ± 1 in-lb

7




AC002725AB

<ECLIPSE SPYDER>

1.4 ± 0.1 N·m
12 ± 1 in-lb

7



AC002726AB

REAR SPEAKER REMOVAL STEPS

- REAR SEAT (REFER TO GROUP 52A, REAR SEAT [P.52A-23.](#))
- REAR SEATBELT (REFER TO GROUP 52A, REARSEATBELT [P.52A-23.](#))

REAR SPEAKER REMOVAL STEPS

- QUARTER TRIM, LOWER (REFER TO GROUP 52A, TRIMS [P.52A-10.](#))
- 7. REAR SPEAKER


AMPLIFIER

REMOVAL AND INSTALLATION

M1544004100080

⚠ WARNING

Before removing a seat equipped with the side air bag module, refer to GROUP 52b, SRS Service Precautions



AC003982 AB

AMPLIFIER REMOVAL STEPS

1. SEAT ANCHOR COVER
2. FRONT PASSENGER'S SEAT ASSEMBLY
3. DIN CABLE

AMPLIFIER REMOVAL STEPS

4. HARNESS CONNECTOR
5. AMPLIFIER

NOTE: Install each seat assembly mounting bolt in every installation location, then tighten to the specified torque.


ANTENNA

REMOVAL AND INSTALLATION


M1544002900080

< ECLIPSE >

<GLASS ANTENNA>



<MAST ANTENNA>



AC004031 AB

**ANTENNA FEEDER CABLE
REMOVAL STEPS <VEHICLES
WITH GLASS ANTENNA>**


1. RADIO, TAPE PLAYER, CD PLAYER AND CD AUTO CHANGER (REFER TO [P.52A-10.](#))
 - FLOOR CONSOLE (REFER TO GROUP 52A, FLOOR CONSOLE [P.52A-10.](#))
 - FRONT PASSENGER'S SEAT (REFER TO GROUP 52A, FRONT SEAT [P.52A-10.](#))
 - QUARTER TRIM LOWER (RH SIDE, REFER TO GROUP 52A, TRIMS [P.52A-10.](#))
2. ANTENNA FEEDER CABLE (FRONT SIDE.)
 - QUARTER TRIM UPPER (RH SIDE, REFER TO GROUP 52A, TRIMS [P.52A-10.](#))
 - LIFTGATE UPPER TRIM (RH SIDE, REFER TO GROUP 42, LIFTGATE – LIFTGATE TRIM [P.52A-10.](#))
3. ANTENNA FEEDER CABLE (REAR SIDE.)

**ANTENNA FEEDER CABLE
REMOVAL STEPS <VEHICLES
WITH MAST ANTENNA>**


1. RADIO, TAPE PLAYER, CD PLAYER AND CD AUTO CHANGER (REFER TO [P.52A-10.](#))
 - FLOOR CONSOLE (REFER TO GROUP 52A, FLOOR CONSOLE [P.52A-10.](#))
 - FRONT DRIVER'S SEAT (REFER TO GROUP 52A, FRONT SEAT [P.52A-10.](#))
 - REAR SEAT (REFER TO GROUP 52A, REAR SEAT [P.52A-10.](#))
 - QUARTER TRIM LOWER (LH SIDE, REFER TO GROUP 52A, TRIMS [P.52A-10.](#))
2. ANTENNA FEEDER CABLE
MAST ANTENNA REMOVAL STEPS
 5. MAST ANTENNA
 6. NUT
 7. INSULATOR
 - REAR SIDE TRIM (LH SIDE, REFER TO GROUP 52A, TRIMS [P.52A-10.](#))
5. ANTENNA BASE

<ECLIPSE SPYDER>

<MAST ANTENNA>



<MOTOR ANTENNA>



AC003983 AB

**ANTENNA FEEDER CABLE
REMOVAL STEPS**

1. RADIO, TAPE PLAYER, CD PLAYER AND CD AUTO CHANGER (REFER TO [P.52A-10.](#))
- FLOOR CONSOLE (REFER TO GROUP 52A, FLOOR CONSOLE [P.52A-10.](#))
- FRONT DRIVER'S SEAT (REFER TO GROUP 52A, FRONT SEAT [P.52A-10.](#))

**ANTENNA FEEDER CABLE
REMOVAL STEPS (Continued)**

- REAR SEAT (REFER TO GROUP 52A, REAR SEAT [P.52A-10.](#))
 - QUARTER TRIM LOWER (LH SIDE, REFER TO GROUP 52A, TRIMS [P.52A-10.](#))
2. ANTENNA FEEDER CABLE


TSB Revision

**MAST ANTENNA REMOVAL STEPS
<VEHICLES WITH MAST
ANTENNA>**

3. MAST ANTENNA
4. NUT
5. INSULATOR
 - TRUNK TRIM (REFER TO GROUP 52A, TRIMS P.52A-10.)
6. ANTENNA BASE

**MOTOR ANTENNA REMOVAL
STEPS <VEHICLES WITH MOTOR
ANTENNA>**

4. RING NUT
5. INSULATOR
7. ANTENNA POLE
 - TRUNK TRIM (REFER TO GROUP 52A, TRIMS P.52A-10.)
8. MOTOR ANTENNA ASSEMBLY
9. DRAIN HOSE



GLASS ANTENNA CHECK

M1544005200068

1. Wrap an aluminum foil around the tester probe as shown.

⚠ CAUTION

Be careful not to damage the print wire.


2. Check continuity while pressing the aluminum foil along the antenna print wire.

ANTENNA INSPECTION

M1544003000109


MOTOR ANTENNA ASSEMBLY INSPECTION

1. Remove the motor antenna assembly connector.
2. Connect the circuits shown in the solid lines.
3. Check that antenna extends when the circuit shown in the dotted lines is connected.
4. Check that the antenna retracts when the circuit shown in the dotted lines is disconnected.




ANTENNA POLE REPLACEMENT

1. Remove the ring nut.




2. After turning the ignition switch to ACC or ON, turn the radio switch to ON to raise the antenna pole, and remove it, together with the rack cable.



3. Draw out the antenna pole to the maximum extension.

NOTE: If there is a bend in the motor end of the rack cable remove the bend.

4. Insert the rack cable into the motor assembly with the rack cable teeth facing the luggage compartment room side.




5. Turn the rack cable teeth towards the rear of the vehicle (right 90) so that the rack cable meshes with the motor gear.

6. If the rack cable pulls out with no resistance when it is lightly pulled, then the cable is not meshed with the motor gear, so check that there are no bends in the end of the rack cable, and then repeat step (4) and (5) above.

7. Set the antenna pole vertically and turn the radio switch OFF to wind up the rack cable. Insert the antenna to the motor antenna side to align it with the wound-up rack cable.

8. After tightening the ring nut, check the movement of the antenna by turning the radio switch ON and OFF.




REAR WINDOW DEFOGGER

ON-VEHICLE SERVICE

PRINTED-HEATER LINES CHECK

M1543001800076

1. Run engine at 2,000 r/min. Check heater element with battery at full.
2. Turn "ON" rear window defogger switch. Measure heater element voltage with circuit tester at rear window glass centre A. Condition is good if it indicates about 6 V.
3. If 12 V is indicated at A, there is a break in the negative terminals from A. Move test bar slowly to negative terminal to detect where voltage changes suddenly (0V).
4. If 0 V is indicated at A, there is a break in the positive terminals from A. Defect where the voltage changes suddenly (12 V) in the same method described above.



REAR WINDOW DEFOGGER SWITCH


REMOVAL AND INSTALLATION

Refer to GROUP 55, Heater Control Assembly and Blower Switch Assembly [P.55-26](#).

M1543006200091

INSPECTION


M1543006300076



SWITCH POSITION	TESTER CONDITION	SPECIFIED CONDITION
OFF	3 - 10	Less than two ohm
ON	3 - 10 3 - 12	Less than two ohm

DEFOGGER RELAY CHECK

M1543006800071



BATTERY VOLTAGE	TERMINAL NO. TO BE CONNECTED TO BATTERY	SPECIFIED CONDITION
Supplied	1 – 3	2 – 5
Not supplied	–	1 – 3

MULTI-CENTER DISPLAY

TROUBLE SYMPTOM CHART


M1543007200221

SYMPTOM	CHECK STEP NO.	REFERENCE
Screen is not displayed.	1	P.54A-191
Compass is not displayed.	2	P.54A-198
The compass is not displayed correctly.	3	P.54A-202
The outside temperature screen displays "E0°F" (outside temperature sensor open circuit) or "-E5°F" (outside temperature sensor short circuit) These are error messages.	4	P.54A-203
The outside temperature and compass screen do not change.	5	P.54A-206
Information about the radio system is not displayed.	-	P.54A-137

SYMPTOM PROCEDURES




INSPECTION PROCEDURE 1: Screen is not Displayed.

Multi Center Display Power Supply and Ground Circuit



W0S10M04A
AC004735AB

TSB Revision



CIRCUIT OPERATION

The multi-center display is energized by the battery through the ignition switch (ACC) and (IG1).

TROUBLESHOOTING HINTS

- Malfunction of the multi-center display
- Damaged harness wires and connectors

TECHNICAL DESCRIPTION (COMMENT)

The ground circuit, the battery circuit, the ignition switch (ACC) circuit or the ignition switch (IG1) circuit is suspected to be open or defective.

DIAGNOSIS

Required Special Tool:

- MB991223: Harness Set


STEP 1. Check the multi-center display ground circuit at the multi-center display connector C-09 by backprobing.


- (1) Do not disconnect the multi-center display connector C-09 and measure at the harness side.
- (2) Measure the resistance between terminal 6 and ground by backprobing.

Q: Is the resistance value less than two ohm?

YES : Go to Step 4 .

NO : Go to Step 2 .






STEP 2. Check the multi-center display connector C-09 for damage.

Q: Is the multi-center display connector C-09 in good condition?

YES : Go to Step 3 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-9](#) .





STEP 3. Check the harness wires between multi-center display connector C-09 and ground.

NOTE: After checking joint connector C-78, check the wires. If joint connector C-78 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#).

Q: Is the harness wires between multi-center display connector C-09 and ground in good condition?

YES : There is no action to be taken.

NO : Repair them. The multi-center display should work normally.



STEP 4. Check the multi-center display power supply circuit (battery) at the multi-center display connector C-09 by backprobing.


(1) Do not disconnect the multi-center display connector C-09 and measure at the harness side.

(2) Measure the voltage between terminal 1 and ground by backprobing.

Q: Is the voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 7 .

NO : Go to Step 5.




STEP 5. Check multi-center display connector C-09 for damage.

Q: Is multi-center display connector C-09 in good condition?

YES : Go to Step 6 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.36-4. The multi-center display should work normally.





STEP 6. Check the harness wires between C-09 and battery.

NOTE: After checking joint connector C-78 and intermediate connector C-89, check the wires. If joint connector C-78 and intermediate connector C-89 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.52A-9 .

Q: Is the harness wires between C-09 and battery in good condition?

YES : There is no action to be taken.

NO : Repair them. The multi-center display should work normally.



STEP 7. Check the multi-center display power supply circuit [ignition switch (ACC)] at the multi-center display connector C-09 by backprobing.

- (1) Do not disconnect the multi-center display connector C-09 and measure at the harness side.
- (2) Turn the ignition switch to "ACC" position.
- (3) Measure the voltage between terminal 3 and ground by backprobing.

Q: Is the voltage approximately 12 volts (battery positive voltage)?

YES : Go to Step 10 .


NO : Go to Step 8 .

STEP 8. Check multi-center display connector C-09 for damage.

Q: Is multi-center display connector C-09 in good condition?

YES : Go to Step 9 .

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#). The multi-center display should work normally.






STEP 9. Check the harness wires between C-09 and ignition switch (ACC).


NOTE: After checking joint connector C-78 and junction block connector C-101 and C-104, check the wires. If joint connector C-78 and junction block connector C-101 and C-104 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#) .

Q: Is the harness wires between C-09 and ignition switch (ACC) in good condition?

YES : There is no action to be taken.

NO : Repair them. The multi-center display should work normally.





STEP 10. Check the multi-center display power supply circuit [ignition switch (IG1)] at the multi-center display connector C-09 by backprobing.

- (1) Do not disconnect the multi-center display connector C-09 and measure at the harness side by backprobing.
- (2) Turn the ignition switch to "ON" position.
- (3) Measure the voltage between terminal 2 and ground by backprobing.

Q: Is the voltage approximately 12 volts (battery positive voltage).

YES : Replace the multi-center display. The multi-center display should work normally.


NO : Go to Step 11.

STEP 11. Check the multi-center display connector C-09 for damage.

Q: Is multi-center display connector C-09 in good condition?

YES : Go to Step 12.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). The multi-center display should work normally.






STEP 12. Check the harness wires between multi-center display connector C-09 and ignition switch (IG1).

NOTE: After checking joint connector C-78 and junction block connector C-101 and C-104, check the wires. If joint connector C-78 and junction block connector C-101 and C-104 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.00E-2.

Q: Is the harness wires between multi-center display connector C-09 and ignition switch (IG1) in good condition?


YES : There is no action to be taken.

NO : Repair them. The multi-center display should work normally.





INSPECTION PROCEDURE 2: Compass is not Displayed.


Compass Circuit



W1S11M04AA
AAC004629 AB



TSB Revision



CIRCUIT OPERATION.

Compass sensor signal through the compass-ECU and multi-center display.

TROUBLESHOOTING HINTS

- Malfunction of the compass-ECU
- Damaged harness wires and connectors

TECHNICAL DESCRIPTION (COMMENT)

If the compass is only not displayed on the multi-center display, the cause may be a malfunction of the compass-ECU.

DIAGNOSIS

Required Special Tool:




- MB991223: Harness Set

STEP 1. Check the compass-ECU connector C-38 and compass sensor connector D-23 for damage.


Q: Are the compass-ECU connector C-38 and compass sensor D-23 in good condition?

YES : Go to Step 2.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).




CONNECTOR: D-23 <ECLIPSE>




AC003545 AD

CONNECTORS: D-23 <ECLIPSE SPYDER>




AC003547 AC

CONNECTOR: C-38



AC003598 AJ

CONNECTORS: C-09, C-37



AC003598 AI

STEP 2. Check the compass sensor connector D-23 and compass-ECU connector C-38 by backprobing.

- (1) Do not disconnect the compass sensor connector D-23 and compass-ECU connector C-38, measure at the harness side.
- (2) Measure the resistance between compass sensor connector D-23 and compass-ECU connector C-38 by backprobing.

COMPASS-ECU CONNECTOR C-38 TERMINAL NO.	COMPASS SENSOR CONNECTOR D-23 TERMINAL NO.	CONDITION
1	5	Should be less than two ohm
2	2	
3	3	
4	4	
6	1	
5	Shield wire between compass-ECU and compass sensor	

Q: Is the resistance value less than two ohm?

YES : Go to Step 3.


NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

STEP 3. Check the compass-ECU connector C-37 and multi-center display connector C-09 for damage.

Q: Are the compass-ECU connector C-37 and multi-center display connector C-09 in good condition?

YES : Go to Step 4.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).



STEP 4. Check the compass-ECU connector C-37 and multi center display connector C-09 by backprobing.

- (1) Do not disconnect the compass-ECU connector C-37 and multi-center display connector C-09, measure at the harness side.
- (2) Measure the resistance between compass-ECU connector C-37 and multi-center display connector C-09 by backprobing.

COMPASS-ECU CONNECTOR C-37 TERMINAL NO.	MULTI-CENTER DISPLAY CONNECTOR C-09 TERMINAL NO.	CONDITION
11	20	Should be less than two ohm
13	18	
14	16	
15	19	
16	13	
17	17	
18	Shield wire between compass-ECU and multi-center display	

Q: Is the resistance value less than two ohm?

YES : Replace the compass-ECU or compass sensor.

NO : Repair or replace it. Refer to GROUP 8W1, Harness Connector Inspection [P.00E-2](#).

INSPECTION PROCEDURE 3: The compass is Not Corretly.

STEP 1. Check the vehicle location

Q: Are there any constructions, such as high-voltage wires or a steel bridge, which might affect the compass sensor?

YES : After moving to a location where the magnetic field is stable, check the faulty condition again.

NO : Go to Step 2.

STEP 2. Correct magnetization

Q: Was magnetization corrected?

YES : Go to Step 3.

NO : Correct magnetization. (Refer to [P.54A-212](#).)

STEP 3. Correct magnetic declination

Q: Was magnetic declination corrected?

YES : Go to Step 4.

NO : Correct the magnetic declination. (Refer to [P.54A-210](#).)

STEP 4. Demagnetize


Q: Was that demagnetized?

YES : Replace the compass sensor.




NO : Demagnetize it. (Refer to [P.54A-212](#).)

INSPECTION PROCEDURE 4: The Outside Temperature Screen Displayed "E0°F" (Ambience Sensor Open Circuit) or "-E5°F" (Ambience Sensor Short Circuit) These are Error message.

Ambience Sensor Circuit



AC004381



CIRCUIT OPERATION

The ambience sensor signal sent to multi-center display.

TECHNICAL DESCRIPTION (COMMENT)


The ambience circuit is suspected to be open or short.

TROUBLESHOOTING HINTS

- Malfunction of the ambience sensor.

TSB Revision

- Damaged harness wires and connectors




STEP 1. Check the ambience sensor connector A-29 for damage.

Q: Is the ambience sensor connector A-29 in good condition?

YES : Go to Step 2.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).





STEP 2. Check the harness wires between ambience sensor connector A-29 and multi-center display connector C-09.


NOTE: After checking intermediate connector C-89, check the wires. If intermediate connector C-89 is damaged, repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#).

Q: Is the harness wires between ambience sensor connector A-29 and multi-center display connector C-09 in good condition?

YES : Go to Step 3.

NO : Repair them. The multi-center display should work normally.





STEP 3. Check the ambience sensor

- (1) Remove the front bumper.
- (2) Remove the ambience sensor connector [P.54A-213](#).
- (3) Measure the resistance between the ambience connector sensor terminals at two or more temperature condition.


Q: Does the resistance value exist within the characteristic graph?

YES : There is no action to be taken.

NO : Replace the ambience sensor.





INSPECTION PROCEDURE 5: The Outside Temperature and Compass Screen Do Not Change.

Vehicle Speed Sensor Circuit



AC004382

TSB Revision



CIRCUIT OPERATION

Vehicle speed sensor signal is sent to multi-center display.

TECHNICAL DESCRIPTION (COMMENT)

Outside temperature and compass display on multi-center display won't be updated until vehicle speed gets 6.2 mph (10km/h) or more.

TROUBLESHOOTING HINTS

- Malfunction of the vehicles speed sensor.
- Malfunction of the multi-center display.
- Damaged harness wires and connectors

DIAGNOSIS

STEP 1. Check the speedometer

Q: Is the speedometer in good condition?

YES : Go to Step 2.




NO : Refer to Combination Meter – Troubleshooting [P.52A-9](#).

STEP 2. Check the connector between vehicles speed sensor connector B-39 and multi-center display connector C-09 for damage.

Q: Are the vehicles speed sensor connector B-39 and multi-center display connector C-09 in good condition?

YES : Go to Step 3.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection [P.52A-23](#).







STEP 3. Check the harness wires between vehicles speed sensor connector B-39 and multi-center display connector C-09.

NOTE: After checking intermediate connector B-36 and C-28, joint connector C-77, check the wires. If intermediate connector B-36 and C-28, joint connector C-77 are damaged, repair or replace them. Refer to GROUP 00E, Harness Connector Inspection P.36-4.

Q: Is the harness wires between vehicles speed sensor connector B-39 and multi-center display connector C-09 in good condition?

YES : Replace the multi-center display.

NO : Repair or replace it. Refer to GROUP 00E, Harness Connector Inspection P.52A-9.






ON-VEHICLE SERVICE**COMPASS CALIBRATION**

M1543013800028

One Turn Magnetic Compensation


The compass is self-calibrating under normal driving conditions. It is not necessary to manually calibrate the compass. If manual calibration is desired, follow these instructions.

1. Engine started.
2. Display the compass on the multi-center display.
3. Press and hold the "H" switch until "-- --" appears in the display.
4. Release the switch to enter the calibration mode.
5. Drive very slowly in a circle until "-- --" disappears.

**Deflection Angle Compensation****COMPASS CALIBRATION**


Under certain circumstances, as during a long distance cross country trip, it will be necessary to adjust for compass variance. Compass variance is the difference between earth's magnetic north and true geographic north.

If not adjusted to account for compass variance, compass could give false readings.




ADJUST FOR COMPASS VARIANCE


1. With showing the compass, keep pressing "M" switch for two second or more.
The current zone umber will appear upon release.



2. Find current location and variance zone number on the zone map.



3. Press the "H" switch repeatedly until the new zone number.



4. Pressing the "M" switch will exit zone entry mode.
This area code number should remain in the battery off.
If the compass deviates from the correct indication soon after repeated adjustment, have the compass checked at refer to [P.54A-210](#).

NOTE: Do not install the ski rack, antenna, etc., which are attached to the vehicle by means of a magnet. They affect the operation of compass.

NOTE: The compass may not indicate the correct compass direction in the place shown below:

- Tunnels
- Railroads
- Underpass/Overpass
- Transforming station
- Large metal structures
- Area over the subway

NOTE: The compass returns to the correct compass direction vehicle moves to an area where the geomagnetism is stabilized.


VEHICLE MAGNETIC COMPENSATION

M1543009700073


Demagnetization and correction method

1. Demagnetize the body using a commercial demagnetizer.


COMMERCIAL DEMAGNETIZER



AC001246AB



FRONT



AC001247AB

2. While keeping the distance between the tip of demagnetizer and the roof panel to approximately 5 cm (2.0 inches), move the demagnetizer slowly with a sweeping manner on the rear-half surface of roof panel.

⚠ CAUTION

If the tip of demagnetizer touches the roof panel, the magnetizing condition of body becomes worse to the contrary. Absolutely avoid this.





3. Slowly draw the demagnetizer apart from the body. Turn off the switch of demagnetizer when it is apart from the body more than 5 cm (2.0 inches).

⚠ CAUTION

If the demagnetizer is turned off near the body or it is suddenly separated from the body, the magnetizing condition of body becomes worse to the contrary. Absolutely avoid these.

REMOBAL AND INSTALLATION

M1543013600035



AC002457AB

AMBIENCE SENSOR REMOVAL STEPS

- FRONT BUMPER (REFER TO GROUP 51, FRONT BUMPER P.51-3.)

1. AMBIENCE SENSOR

COMPASS SENSOR REMOVAL

2. COMPASS SENSOR

COMPASS-ECU REMOVAL STEPS

- COWL SIDE TRIM (REFER TO GROUP 52A, TRIMS P.52A-10.)

3. COMPASS-ECU

MULT-CENTER DISPLAY REMOVAL STEPS





4. CENTAR PANEL (REFER TO GROUP 52A, INSTRUMENT PANEL P.52A-4.)

5. CENTER HOOD (REFER TO GROUP 52A, INSTRUMENT PANEL P.52A-4.)

6. MULTI-CENTER DISPLAY

SPECIAL TOOLS

M1543000600262

TOOL	TOOL NUMBER AND NAME	REPLACED THE MILLER TOOL NUMBER	APPLICATION
    MB991223AC	MB991223 A: MB991219 B: MB991220 C: MB991221 D: MB991222 Harness set A: Test harness B: LED harness C: LED harness adapter D: Probe	MB991223	Making voltage and resistance measurements during troubleshooting A: Connect pin contact pressure inspection B: Power circuit inspection C: Power circuit inspection D: Commercial tester connection

THEFT ALARM

THEFT ALARM DIAGNOSIS

The theft-alarm system is controlled by the Simplified Wiring System (SWS). For troubleshooting, refer to GROUP 54B, SWS Diagnosis – Symptom Chart [P.54B-9](#).

REMOVAL AND INSTALLATION

Theft alarm system component parts

- Theft alarm horn and theft alarm horn relay (refer to [P.54A-89](#).)
- Door switch (refer to GROUP 42, Door – Door Assembly [P.42-70](#).)
- Door lock actuator and door lock key cylinder switch (refer to GROUP 42, Door - Door Handle and Latch [P.42-79](#).)
- Hood switch (refer to GROUP 42, Hood [P.42-7](#).)
- Liftgate lock key cylinder switch and liftgate latch switch (refer to GROUP 42, liftgate – liftgate handle and latch [P.42-89](#).)
- Key reminder switch (refer to [P.54A-27](#).)

SPECIFICATIONS

FASTENER TIGHTENING SPECIFICATIONS

M1544004600063

ITEMS	SPECIFICATIONS
Amplifier mounting screw	1.5 ±0.5 N·m (13 ± 4 in-lb)
Door speaker mounting screw	1.4 ±0.1 N·m (12 ± 1 in-lb)
Engine coolant temperature gauge unit	16 ±2 N·m (11 ± 2 ft-lb)
Fog light assembly mounting bolt	4.9 ±0.7 N·m (43 ± 6 in-lb)
Front seat mounting nut	30 ±5 N·m (22 ± 4 ft-lb)
Front seat mounting bolt	44 ±10 N·m (33 ± 7 ft-lb)
Headlight mounting bolt	4.9 ±0.7 N·m (43 ± 6 in-lb)
High-mounted stop light mounting bolt	4.9 ±0.7 N·m (43 ± 6 in-lb)
Horn mounting bolt	11 ±2 N·m (96 ± 17 in-lb)
Radio, tape player, CD player and CD auto changer mounting screw	1.4 ±0.1 N·m (12 ± 1 in-lb)
Radio bracket mounting bolt	1.4 ±0.1 N·m (12 ± 1 in-lb)
Rear combination light mounting nut	4.9 ±0.7 N·m (43 ± 6 in-lb)
Rear speaker mounting screw	1.4 ±0.1 N·m (12 ± 1 in-lb)
Tweeter mounting nut	1.4 ±0.1 N·m (12 ± 1 in-lb)

SERVICE SPECIFICATIONS

M1543000300056

<IMMOBILIZER SYSTEM>

ITEM	STANDARD VALUE
Ignition key ring antenna resistance Ω	2 or less

<COMBINATION METER>

ITEMS		STANDARD VALUE
Speedometer indication allowance range mph (km/h)	20 (32)	19 – 22 (31 – 35)
	40 (64)	38 – 44 (61 – 71)
	60 (97)	57 – 66 (92 – 106)
	80 (129)	76 – 88 (122 – 142)
	100 (161)	94 – 110 (151 – 177)
Tachometer indication allowance range r/min	700	+100
	3,000	+150
	5,000	+250
	6,000	+300
Fuel gauge unit resistance Ω	Float point "F"	3 – 5
	Float point "E"	110 – 112
Fuel gauge unit float height mm (in)	A (Float point "F")	180.3 (7.10)
	B (Float point "E")	18.8 (0.74)
Engine coolant temperature gauge unit resistance Ω		104 + 13.5

TSB Revision

ITEMS		STANDARD VALUE
Fuel gauge resistance Ω	Power supply and ground	Approximately 233
	Power supply and fuel gage	Approximately 108
	Fuel gage and ground	Approximately 125
Engine coolant temperature gauge resistance Ω	Power supply and ground	Approximately 176
	Power supply and engine coolant temperature	Approximately 54
	Engine coolant temperature and ground	Approximately 230

<HEADLIGHT>

ITEMS		STANDARD VALUE	LIMIT
Headlight aiming	Vertical direction	21 mm (0.8 in) below horizontal (H)	–
	Horizontal direction	Position where the 15° sloping section intersects the vertical line (V)	–
Headlight intensity cd		–	20,000 or more

<FOG LIGHT>

ITEMS		STANDARD VALUE	LIMIT
Fog light aiming	Vertical direction	151 mm (5.9 in) below horizontal (H)	–
	Horizontal direction	Parallel to direction of vehicle travel	–

SEALANT

M1543000500050

<COMBINATION METER>

ITEM	SPECIFIED SEALANT	REMARK
Engine coolant temperature gauge unit threaded portion	3M™ AAD part No. 8731, Loctite®242 Blue Service Tool Removable or equivalent	Drying sealant