

GROUP 70

COMPONENT
LOCATIONS



CONTENTS

FUSIBLE LINK, FUSE AND IOD OR STORAGE CONNECTOR	70-2	RELAY	70-9
INSPECTION TERMINAL	70-3	SENSOR	70-10
GROUNDING	70-4	CONTROL UNIT	70-17
GROUNDING CABLE	70-8	SOLENOID AND SOLENOID VALVE	70-20
		OTHER DEVICES	70-22





FUSIBLE LINK, FUSE AND IOD OR STORAGE CONNECTOR


M1701000100227

NAME	SYMBOL	NAME	SYMBOL
Fuses No.1 to 4	E	Fusible link No.1 to 5	B
Fuses No.6 to 25 (Engine compartment)	C	Fusible link No.26	A
		Fusible link No.27	D
Fuses No.5 to 24 (Passenger compartment)	E	IOD or storage connector	C



AC102219 AE









INSPECTION TERMINAL

M1701000200224

NAME	SYMBOL	NAME	SYMBOL
Data link connector	B	Engine speed detection connector	A




AC102219AC




GROUNDING

M1701000300221

<ECLIPSE>



















<ECLIPSE SPYDER>







AC102225AB

NOTE: 1 to 17 numbers correspond to the body ground point numbers in CIRCUIT DIAGRAMS.











GROUNDING CABLE

M1701001000182

<2.4L ENGINE>



<3.0L ENGINE>




AC102226AB



RELAY

M1701000400217

NAME	SYMBOL	NAME	SYMBOL
A/C compressor relay	A	Fuel pump relay (2)	B
A/T control relay	A	Horn relay	A
Blower relay	B	MFI relay	A
Defogger relay	B	Power window relay	B
Fan control relay	A	Starter relay <M/T>	A
Fog light relay	A	Theft-alarm horn relay	A
Fuel pump relay (1)	B		



AC102219AD




SENSOR



M1701000600244

NAME	SYMBOL	NAME	SYMBOL
A/C compressor assembly (with built-in lock sensor)	R	Knock sensor <3.0L Engine>	O
A/T control solenoid valve assembly (with built-in A/T fluid temperature sensor)	K	Left bank heated oxygen sensor (front) <3.0L Engine>	U
Air thermo sensor <A/C>	W	Left bank heated oxygen sensor (rear) <3.0L Engine>	T
Ambient temperature sensor <Multi center display>	J	Manifold differential pressure sensor <2.4L Engine>	B
Camshaft position sensor <2.4L Engine>	H	Manifold differential pressure sensor <3.0L Engine>	P
Compass sensor <Multi center display>	Y	Output shaft speed sensor <A/T>	E
Crankshaft position sensor <2.4L Engine>	F	Right bank heated oxygen sensor (front) <3.0L Engine>	N
Crankshaft position sensor <3.0L Engine>	S	Right bank heated oxygen sensor (rear) <3.0L Engine>	Z
Distributor assembly (with built-in top dead center sensor) <3.0L Engine>	M	Side impact sensor <Side air bag>	b
Engine coolant temperature sensor <2.4L Engine>	I	Thermistor sensor <A/C>	X
Engine coolant temperature sensor <3.0L Engine>	V	Throttle position sensor <2.4L Engine>	C
Fuel tank differential pressure sensor	a	Throttle position sensor <3.0L Engine>	Q
Fuel pump module (with built-in fuel temperature sensor)	a	Vehicle speed sensor <M/T>	D
Heated oxygen sensor (front) <2.4L Engine>	G	Volume air flow sensor	L
Heated oxygen sensor (rear) <2.4L Engine>	c	Wheel speed sensor (front) <ABS>	d
Input shaft speed sensor <A/T>	E	Wheel speed sensor (rear) <ABS>	e
Knock sensor <2.4L Engine>	A		


<2.4L ENGINE>




<3.0L ENGINE>



<ECLIPSE>





<ECLIPSE SPYDER>




AC102253AC


NOTE: The * symbols indicate also equipped at the right side.

A <2.4L ENGINE>


AC106202 AB

B <2.4L ENGINE>


AC101167AC

C <2.4L ENGINE>

ACX02472AB

D



ACX02473AB

E

ACX02474 AB

F <2.4L ENGINE>



CRANKSHAFT
POSITION
SENSOR
CONNECTOR











AC106203 AB



G <2.4L ENGINE>

HEATED OXYGEN
SENSOR (FRONT)
CONNECTOR




AC106204 AB




O <3.0L ENGINE (WITHOUT VARIABLE INDUCTION CONTROL (VIC) SYSTEM)>


AC106435 AB

O <3.0L ENGINE (WITH VARIABLE INDUCTION CONTROL (VIC) SYSTEM)>


AC106186 AB

P <3.0L ENGINE>



ACX02483 AH

Q <3.0L ENGINE>



ACX02484 AJ

R <3.0L ENGINE>











AC106208 AB









S <3.0L ENGINE (WITHOUT VARIABLE INDUCTION CONTROL (VIC) SYSTEM)>

AC106207 AB

S <3.0L ENGINE (WITH VARIABLE INDUCTION CONTROL (VIC) SYSTEM)>

AC106219 AB






















CONTROL UNIT

M1701000700199

NAME	SYMBOL	NAME	SYMBOL
ABS-ECU	A	Immobilizer-ECU	J
Auto-cruise control-ECU	F	Motor antenna assembly (with built-in motor antenna-ECU) <ECLIPSE SPYDER>	O
Automatic compressor controller <A/C>	G		
Column-ECU	D		
Compass-ECU <Multi center display>	L	Multi center display unit	E
Convertible top control module <ECLIPSE SPYDER>	N	Powertrain control module <A/T>	K
		SRS-ECU	I
Engine control module <M/T>	K	Sunroof motor assembly (with built-in CPU) <ECLIPSE>	M
ETACS-ECU	H		
Fan controller	C	Water shut valve controller <ECLIPSE>	P
Front-ECU	B		








SOLENOID AND SOLENOID VALVE


M1701000800215

NAME	SYMBOL	NAME	SYMBOL
A/T control solenoid valve assembly	E	Evaporative emission purge solenoid valve <3.0L Engine (with variable induction control (VIC) system)>	G
Auto-cruise control vacuum pump (with built-in control valve and release valve)	A	Evaporative emission purge solenoid valve <3.0L Engine (without variable induction control (VIC) system)>	D
EGR solenoid valve <2.4L Engine>	C	Evaporative emission ventilation solenoid	F
EGR solenoid valve <3.0L Engine>	D	Hydraulic unit (with built-in ABS solenoid valve)	B
Evaporative emission purge solenoid valve <2.4L Engine>	C	Variable induction control solenoid valve <3.0L Engine (with variable induction control (VIC) system)>	D


<2.4L ENGINE>




<3.0L ENGINE>











<ECLIPSE>



<ECLIPSE SPYDER>






OTHER DEVICES


M1701005600186

NAME	SYMBOL	NAME	SYMBOL
A/C compressor assembly (built-in A/C refrigerant temperature switch) <2.4L Engine>	D	Idle air control motor <3.0L Engine>	F
A/C compressor assembly (built-in A/C refrigerant temperature switch) <3.0L Engine>	G	Power steering pressure switch <2.4L Engine>	C
Dual pressure switch	A	Power steering pressure switch <3.0L Engine>	E
Idle air control motor <2.4L Engine>	B		



<2.4L ENGINE>








<3.0L ENGINE>



AC102271AB





NOTES